
Service Manual

(Mono Bloc) Air-to-Water Heatpump System



Mono Bloc Unit WH-MHF09D3E8 WH-MHF12D9E8

WARNING

This service information is designed for experienced repair technicians only and is not designed for use by the general public. It does not contain warnings or cautions to advise non-technical individuals of potential dangers in attempting to service a product. Products powered by electricity should be serviced or repaired only by experienced professional technicians. Any attempt to service or repair the product or products dealt with in this service information by anyone else could result in serious injury or death.



In order to avoid frostbite, be assured of no refrigerant leakage during the installation or repairing of refrigerant circuit.

Panasonic[®]

© Panasonic Appliances Air-Conditioning (M) Sdn. Bhd. 2012. Unauthorized copying and distribution is a violation of law.

TABLE OF CONTENTS

| PAGE | | | | | |
|--|--|--|--|--|--|
| 1. Safety Precautions3 | | | | | |
| 2. Specifications5 | | | | | |
| 2.1 WH-MHF09D3E85 | | | | | |
| 2.2 WH-MHF12D9E87 | | | | | |
| 3. Features9 | | | | | |
| 4. Location of Controls and Components10 | | | | | |
| 4.1 Mono Bloc Unit10 | | | | | |
| 5. Dimensions | | | | | |
| | | | | | |
| 5.1 Mono Bloc Unit17 | | | | | |
| 6. Refrigeration and Water Cycle Diagram18 | | | | | |
| 7. Block Diagram20 | | | | | |
| 7.1 WH-MHF09D3E820 | | | | | |
| 7.2 WH-MHF12D9E821 | | | | | |
| 8. Wiring Connection Diagram22 | | | | | |
| 8.1 WH-MHF09D3E822 | | | | | |
| 8.2 WH-MHF12D9E824 | | | | | |
| 9. Electronic Circuit Diagram26 | | | | | |
| 9.1 WH-MHF09D3E826 | | | | | |
| 9.2 WH-MHF12D9E828 | | | | | |
| 10. Printed Circuit Board30 | | | | | |
| 10.1 Water system30 | | | | | |
| 10.2 Refrigerant System32 | | | | | |
| 11. Installation Instruction Mono Bloc Unit34 | | | | | |
| 11.1 Select the Best Location36 | | | | | |
| 11.2 Mono Bloc Unit Installation | | | | | |
| 11.3 Piping Installation37 11.4 Connect The Cord And Cable To Mono bloc | | | | | |
| Unit38 | | | | | |
| 12. Operation and Control43 | | | | | |
| 12.1 Basic Function43 | | | | | |
| 12.2 Water Pump | | | | | |
| 12.3 Pump Down Operation55 12.4 Flow Switch55 | | | | | |
| 12.5 Force Heater Mode Operation | | | | | |
| 12.6 Mono Bloc Unit Safety56 | | | | | |
| 12.7 Auto Restart Control56 | | | | | |
| 12.8 Indication Panel56 | | | | | |
| 12.9 Back-Up Heater Control | | | | | |
| 12.10 Tank Booster Heater Control57 12.11 Base Pan Heater Control (Optional)58 | | | | | |
| 12.11 Base Fair Heater Control (Optional)58 | | | | | |
| 12.13 Sterillization Mode59 | | | | | |
| 12.14 Quiet Operation59 | | | | | |
| 12.15 Anti Freeze Control | | | | | |
| 12.16 Solar Operation (Optional)60 | | | | | |
| 12.17 External Room Thermostat Control (Optional)63 | | | | | |
| 13. Protection Control64 | | | | | |

| | | PAGE |
|----------------------|---|---|
| 13.1 13.2 | Protection Control for All Operations Protection Control for Heating Operation | 64 66 |
| 14. Seı | rvicing Mode | 67 |
| 14.1 14.2 14.3 | | 67 |
| 45 Ma | intenance Guide | |
| | | |
| | oubleshooting Guide | |
| 16.2 16.3 | Refrigeration Cycle System | 71 72 73 |
| 17. Dis | assembly and Assembly Instructions . | |
| 17.10 | To Remove Water Pump To Remove Bottle Complete | 109 110 110 111 111 112 112 |
| 18. Ted | chnical Data | 113 |
| 18.2 18.3 18.4 | Usage Limitation | 115 115 |
| | oloded View and Replacement Parts t | 117 |
| | (Refrigerant System) | |

1. Safety Precautions

- Read the following "SAFETY PRECAUTIONS" carefully before perform any servicing.
- Electrical work and water installation work must be installed or serviced by a licensed electrician and licensed water system installer respectively. Be sure to use the correct rating and main circuit for the model installed.
- The caution items stated here must be followed because these important contents are related to safety. The meaning of each indication used is as below. Incorrect installation or servicing due to ignoring of the instruction will cause harm or damage, and the seriousness is classified by the following indications.

| \triangle | WARNING | This indication shows the possibility of causing death or serious injury. | | |
|----------------|---------|--|--|--|
| $ \leftarrow $ | CAUTION | This indication shows the possibility of causing injury or damage to properties. | | |

• The items to be followed are classified by the symbols:

|--|

 Carry out test run to confirm that no abnormality occurs after the servicing. Then, explain to user the operation, care and maintenance as stated in instructions. Please remind the customer to keep the operating instructions for future reference.

| | (!) WARNING | |
|----|---|------------|
| 1. | Do not modify the machine, part or material during repairing service. | \Diamond |
| 2. | If wiring unit is supplied as repairing part, do not repair or connect the wire even partial wire break. Exchange the whole wiring unit. | \Diamond |
| 3. | Do not wrench the fasten terminal. Pull it out or insert it straightly. | \Diamond |
| 4. | Do not install Mono bloc unit near handrail of veranda. When installing Mono bloc unit at veranda of high rise building, child may climb up to Mono bloc unit and cross over the handrail and causing accident. | \Diamond |
| 5. | Do not use unspecified cord, modified cord, join cord or extension cord for power supply cord. Do not share the single outlet with other electrical appliances. Poor contact, poor insulation or over current will cause electrical shock or fire. | \Diamond |
| 6. | Do not tie up the power supply cord into a bundle by band. Abnormal temperature rise on power supply cord may happen. | \Diamond |
| 7. | Do not insert your fingers or other objects into the unit, high speed rotating fan may cause injury. | 0 |
| 8. | Do not sit or step on the unit, you may fall down accidentally. | \Diamond |
| 9. | Keep plastic bag (packaging material) away from small children, it may cling to nose and mouth thus causing suffocation. | \Diamond |
| 10 | . Do not use pipe wrench to install refrigerant pipe. Using pipe wrench may deform the pipes and cause unit malfunction. | \Diamond |
| 11 | . Do not purchase unauthorized electrical parts for installation, service, maintenance and etc They might cause electrical shock or fire. | \Diamond |
| 12 | . Do not modify the wiring of Mono bloc unit for installation of other components (i.e. heater, etc). Overloaded wiring or wire connection points may cause electrical shock or fire. | 0 |
| 13 | . For electrical work, follow local wiring standard, regulation and this installation instruction. An independent circuit and single outlet must used. If electrical circuit capacity is not enough or defect found in electrical work, it will cause electrical shock or fire. | be |
| 14 | . For water circuit installation work, follow to relevant European and national regulations (including EN61770) and local plumbing and buil regulation codes. | lding |
| 15 | . Must engage an authorized dealer or specialist for installation. If installation is defective, it will cause water leakage, electrical shock or f | fire. |
| 16 | . Install according to this installation instructions strictly. If installation is defective, it will cause water leakage, electrical shock or fire. | |
| 17 | . Only use the supplied or specified installation parts. Else, it may causes Mono bloc unit vibrate, fall, water leakage, electrical shock or fi | re. |
| 18 | . Install at a flat, strong and firm location which is able to withstand the Mono bloc unit's weight. If the location is slanting, or strength is no enough the set will fall and cause injury. | ot |

- 19. This equipment is strongly recommended to be installed with Residual Current Device (RCD) on-site according to the respective national wiring rules or country-specific safety measures in terms of residual current.
- 20. The unit is only for use in a closed water system. Utilization in an open water system may lead to excessive corrosion of the water piping and risk of incubating bacteria colonies, particularly Legionella, in water.
- 21. If there is any doubt about the installation procedure or operation, always contact the authorized dealer for advice and information.
- 22. Select a location where in case of water leakage, the leakage will not cause damage to other properties.
- 23. When installing electrical equipment at wooden building of metal lath or wire lath, in accordance with electrical facility standard, no electrical contact between equipment and building is allowed. Insulator must be installed in between.
- 24. This installation may be subjected to building regulation approval applicable to respective country that may require to notify the local authority before installation.
- 25. Any work carried out on the Mono bloc unit after removing the front panel which is secured by screws, must be carried out under the supervision of authorized dealer and licensed installation contractor.
- 26. This unit must be properly earthed, the electrical earth must not be connected to a gas pipe, water pipe, the earth of a lightening rod or a telephone. Otherwise there is a danger of electrical shock in the event of an insulation breakdown or electrical earth fault in the Mono bloc unit.
- 27. When replace refrigeration circuit components, confirm on usage of specified refrigerant type. Using of refrigerant other than the specified type may cause product damage, burst and injury etc.
- 28. Do not add or replace refrigerant other than the specified type. Equipment may damage or deteriorate in safety due to usage of other refrigerant.

A

CAUTION

- 1. Do not install the Mono bloc unit in areas where there is a risk of flammable gas leakage. There is a risk of fire if flammable gas accumulates near or around the Mono bloc unit
- $\frac{\circ}{\circ}$
- Do not release refrigerant during piping work for installation, re-installation and during repairing a refrigeration parts. Take care of the liquid refrigerant, it may cause frostbite.
- Make sure the power supply cord does not contact with hot part (i.e. water piping). High temperature may cause insulator of power supply cord damage hence electrical shock or fire.
 - , 0
- Do not touch the sharp aluminum fins or edges of metal parts.
 If you are required to handle sharp parts during installation or servicing, please wear hand glove.
- _
- Sharp parts may cause injury.Do not apply excessive force to water pipes that may damage the pipes. If water leakage occurs, it will cause flooding and damage to other properties.
- 0
- Carry out drainage piping as mentioned in installation instructions. If drainage is not perfect, water leakage may happen and may cause damage to properties of the user.
- The piping installation work must be flushed before the Mono bloc unit is connected to remove contaminants. Contaminants may damage the Mono bloc unit components.
- 8. Select an installation location where it is accessible for maintenance.
- 9. Power supply connection to Mono bloc unit.
 - Power supply point should be in easily accessible place for power disconnection in case of emergency.
 - Must follow local national wiring standard, regulation and this installation instruction.
 - Strongly recommended to make permanent connection to a circuit breaker.

For WH-MHF09D3E8:

- Power Supply 1: Use approved 20A 4-poles circuit breaker with a minimum contact gap of 3.0mm.
- Power Supply 2: Use approved 15/16A 2-poles circuit breaker with a minimum contact gap of 3.0mm.

For WH-MHF12D9F8

- Power Supply 1: Use approved 20A 4-poles circuit breaker with a minimum contact gap of 3.0mm.
- Power Supply 2: Use approved 15/16A 2-poles circuit breaker with a minimum contact gap of 3.0mm.
- Power Supply 3: Use approved 15/16A 4-poles circuit breaker with a minimum contact gap of 3.0mm.
- 10. Ensure the correct polarity is maintained throughout all wiring. Otherwise, it will cause electrical shock or fire.
- 11. After installation, the installer is obliged to verify correct operation of the Mono bloc unit. Check the connection point for water leakage during test run. If leakage occurs, it will cause damage to other properties.
- 12. Installation work.
 - Four or more people are required to carry out the installation work. The weight of Mono bloc unit might cause injury if carried by less than four people.

2. Specifications

2.1 WH-MHF09D3E8

| | Item | Unit | Refrigerant System | |
|----------------------------|-------------------|------------------------------|--------------------------------|------------|
| Performance Test Condition | | | EN1 | 4511 |
| | | Condition (Ambient/Water) | A7W35 | A2W35 |
| Heating Capacity | | kW | 9.00 | 9.00 |
| 3 1 | | BTU/h | 30700 | 30700 |
| | | kcal/h | 7740 7740 | |
| COP | | W/W | 4.55 | 3.40 |
| COP | | kcal/hW | 3.91 | 2.92 |
| Air Flow | | m³/min (ft³/min) | 76.8 (| (2710) |
| Refrigeration Control D | Device | | Expansi | on Valve |
| Refrigeration Oil | | cm ³ | FV50S (1600) | |
| Refrigerant (R407C) | | kg (oz) | 2.22 (78.4) | |
| Dina Diameter | Liquid | mm (inch) | 9.52 (3/8) | |
| Pipe Diameter | Gas | mm (inch) | 15.88 (5/8) | |
| | Туре | | Hermetic Motor / Rotary | |
| Compressor | Motor Type | | Brushless (4-poles) | |
| | Rated Output | kW | 3.40 | |
| | Туре | | Propeller Fan | |
| | Material | | PP | |
| F | Motor Type | | Induction (8-poles) | |
| Fan | Input Power | W | | |
| | Output Power | W | 60 | |
| | Fan Speed | rpm | 490 (Top Fan) 530 (Bottom Fan) | |
| | Fin material | | Aluminium (Pre Coat) | |
| Heat Each and and | Fin Type | | Corrugated Fin | |
| Heat Exchanger | Row × Stage × FPI | | 2 × 51 × 18 | |
| | Size (W × H × L) | mm | 881.5 × 1 | 295.4 × 44 |

| Item | | Unit | Mono Blo | c Unit |
|--|----------------------------------|---------------------|----------------------|-----------|
| | Height | mm (inch) | 1410 (55 | i-1/2) |
| Dimension | Width | mm (inch) | 1283 (50 |)-1/2) |
| | Depth | mm (inch) | 320 (12-1 | 19/32) |
| Net Weight | · | kg (lbs) | 166 (3 | 66) |
| Noise Level | | dB-A | 49 | |
| Noise Level | | Power Level dB | 66 | |
| | | Ø | Thre | е |
| Power Source (Pha | ase, Voltage, Cycle) | V | 400 | |
| | | Hz | 50 | |
| Input Power | | kW | 1.98 | 2.65 |
| Maximum Input Power For Mono Bloc Unit | | kW | 6.67 | |
| Power Supply 1: Ph | nase (ø) / Max. Current (A) / Ma | ax. Input Power (W) | Three / 14.7 / 9.67k | |
| Power Supply 2: Ph | nase (ø) / Max. Current (A) / Ma | ax. Input Power (W) | Single / 13.0 | 0 / 3.00k |
| Power Supply 3: Phase (ø) / Max. Current (A) / Max. In | | ax. Input Power (W) | -1-1 | - |
| Starting Current | | A | 3.1 | |
| Running Current | | A | 3.1 | 4.1 |
| Maximum Current For Mono Bloc Unit | | A | 10.4 | ļ |
| Power Factor | | % | 93 | 94 |

| Item | | Unit | Mono Bloc Unit |
|--|----------------|--------|--------------------|
| Power factor means total figure of compressor and outdoor fan motor. | | | |
| Dower Cord | Number of core | | - |
| Power Cord | Length | m (ft) | - |
| Thermostat | | | Electronic Control |
| Protection Device | | | Electronic Control |

| Item | | Unit | Water System | |
|--|-----------------|--------|---------------------------------------|--------------------------------------|
| Performance Test Condition | | | EN14511 | |
| Outdoor . | | mbient | °C | -20 ~ 35 |
| Operation Range | Water Out | et | °C | 25 ~ 65 |
| Internal Pressure Differentia | al | | kPa | 13.3 |
| Refrigerant Pipe Diameter | Liquid | | mm (inch) | 9.52 (3/8) |
| Reingerant Fipe Diameter | Gas | | mm (inch) | 15.88 (5/8) |
| Water Dine Diameter | Inlet | | mm (inch) | 30 (1-3/16) |
| Water Pipe Diameter | Outlet | | mm (inch) | 30 (1-3/16) |
| Water Drain Hose Inner Dia | meter | | mm (inch) | 15.00 (19/32) |
| | Motor Type | Э | | Capacitor Run Induction Motor (5 μF) |
| Pump | No. of Speed | | | 3 |
| | Input Power | | W | 180 |
| Туре | | | | Brazed Plate |
| Hot Water Coil | No. of Plat | es | | 80 |
| Hot water Con | Size (W x | H x L) | mm | 130 × 93 × 325 |
| | Water Flow Rate | | l/min (m³/h) | 25.8 (1.5) |
| Pressure Relief Valve Water Circuit | | kPa | Open: 300, Close: 265 and below | |
| Flow Switch | | | Magnetic Lead Switch | |
| Protection Device | | A | Residual Current Circuit Breaker (40) | |
| Function Vessel | | Volume | ı | 10 |
| Expansion Vessel | • | MWP | bar | 3 |
| Capacity of Integrated Electric Heater | | kW | 3.00 | |

Note:

- Heating capacities are based on outdoor air temperature of 7°C Dry Bulb (44.6°F Dry Bulb), 6°C Wet Bulb (42.8°F Wet Bulb) with controlled water inlet temperature of 30°C and water outlet temperature of 35°C.
- Specification are subjected to change without prior notice for further improvement.

2.2 WH-MHF12D9E8

| | Item | Unit | Refrigerant System | |
|----------------------------|-------------------|------------------------------|--------------------------------|-----------|
| Performance Test Condition | | | EN1 | 4511 |
| | | Condition (Ambient/Water) | A7W35 | A2W35 |
| Heating Capacity | | kW | 12.00 | 12.00 |
| | BTU/r | | 40900 | 40900 |
| | | kcal/h | 10320 10320 | |
| COP | | W/W | 4.40 | 3.23 |
| COP | | kcal/hW | 3.78 | 2.77 |
| Air Flow | | m³/min (ft³/min) | 80.0 | (2830) |
| Refrigeration Control D | Device | | Expans | ion Valve |
| Refrigeration Oil | | cm ³ | FV50S (1600) | |
| Refrigerant (R407C) | | kg (oz) | 2.22 | (78.4) |
| Pipe Diameter | Liquid | mm (inch) | 9.52 (3/8) | |
| Pipe Diameter | Gas | mm (inch) | 15.88 (5/8) | |
| | Туре | | Hermetic Motor / Rotary | |
| Compressor | Motor Type | | Brushless (4-poles) | |
| | Rated Output | kW | 3.40 | |
| | Туре | | Propeller Fan | |
| | Material | | F | PP . |
| Fan | Motor Type | | Induction (8-poles) | |
| ran | Input Power | W | _ | |
| | Output Power | W | 60 | |
| | Fan Speed | rpm | 510 (Top Fan) 550 (Bottom Fan) | |
| | Fin material | | Aluminium (Pre Coat) | |
| Lloot Evolunger | Fin Type | | Corrugated Fin | |
| Heat Exchanger | Row × Stage × FPI | | 2 × 51 × 18 | |
| | Size (W × H × L) | mm | 881.5 × 1295.4 × 44 | |

| Item | | Unit | Mono Bl | oc Unit |
|--|-----------------------------------|---------------------|----------------------|------------|
| | Height | mm (inch) | 1410 (5 | 5-1/2) |
| Dimension | Width | mm (inch) | 1283 (5 | 0-1/2) |
| | Depth | mm (inch) | 320 (12- | 19/32) |
| Net Weight | · | kg (lbs) | 166 (3 | 366) |
| Noise Level | | dB-A | 50 |) |
| Noise Levei | | Power Level dB | 67 | 7 |
| | | Ø | Thre | ee |
| Power Source (Pha | se, Voltage, Cycle) | V | 400 | |
| | | Hz | 50 | |
| Input Power | | kW | 2.73 | 3.72 |
| Maximum Input Pov | wer For Mono Bloc Unit | kW | 7.07 | |
| Power Supply 1: Ph | nase (ø) / Max. Current (A) / Max | ax. Input Power (W) | Three / 10.9 / 7.07k | |
| Power Supply 2: Ph | nase (ø) / Max. Current (A) / Max | ax. Input Power (W) | Single / 13 | .0 / 3.00k |
| Power Supply 3: Phase (ø) / Max. Current (A) / Max. In | | ax. Input Power (W) | Three / 13 | .0 / 9.00k |
| Starting Current | | А | 4.2 | 2 |
| Running Current | | А | 4.2 | 5.7 |
| Maximum Current For Mono Bloc Unit | | А | 10. | 9 |
| Power Factor | | % | 94 | 95 |

| Item | | Unit | Mono Bloc Unit |
|--|----------------|--------|--------------------|
| Power factor means total figure of compressor and outdoor fan motor. | | | |
| Power Cord | Number of core | | - |
| Power Cord | Length | m (ft) | - |
| Thermostat | | | Electronic Control |
| Protection Device | | | Electronic Control |

| Ite | m | | Unit | Water System | |
|--|------------------|--------|--------------|---------------------------------------|--|
| Performance Test Condition | า | | | EN14511 | |
| Operation Dange | Outdoor Ambient | | °C | -20 ~ 35 | |
| Operation Range | Water Outlet | | °C | 25 ~ 65 | |
| Internal Pressure Differentia | al | | kPa | 22.5 | |
| Refrigerent Dine Diemeter | Liquid | | mm (inch) | 9.52 (3/8) | |
| Refrigerant Pipe Diameter | Gas | | mm (inch) | 15.88 (5/8) | |
| Water Dine Diameter | Inlet | | mm (inch) | 30 (1-3/16) | |
| Water Pipe Diameter | Outlet | | mm (inch) | 30 (1-3/16) | |
| Water Drain Hose Inner Dia | meter | | mm (inch) | 15.00 (19/32) | |
| | Motor Type | | | Capacitor Run Induction Motor (5 μF) | |
| Pump | No. of Speed | | | 3 | |
| | Input Power | | W | 180 | |
| | Туре | | | Brazed Plate | |
| Llat Water Cail | No. of Plates | | | 80 | |
| Hot Water Coil | Size (W x H x L) | | mm | 130 × 93 × 325 | |
| | Water Flow Rate | | l/min (m³/h) | 34.4 (2.1) | |
| Pressure Relief Valve Water Circuit | | | kPa | Open: 300, Close: 265 and below | |
| Flow Switch | | | | Magnetic Lead Switch | |
| Protection Device | | | A | Residual Current Circuit Breaker (40) | |
| Europaian Manad | | Volume | I | 10 | |
| Expansion Vessel | • | MWP | bar | 3 | |
| Capacity of Integrated Electric Heater | | | kW | 9.00 | |

Note:

- Heating capacities are based on outdoor air temperature of 7°C Dry Bulb (44.6°F Dry Bulb), 6°C Wet Bulb (42.8°F Wet Bulb) with controlled water inlet temperature of 30°C and water outlet temperature of 35°C.
- Specification are subjected to change without prior notice for further improvement.

3. Features

- Inverter Technology
 - Energy saving
- High Efficiency
- Compact Design

• Environment Protection

- Non-ozone depletion substances refrigerant (R407C)

Easy to use remote control

· Weekly Timer setting

Quality Improvement

- Random auto restart after power failure for safety restart operation
- Gas leakage protection
- Prevent compressor reverse cycle
- Inner protector to protect compressor

Serviceability Improvement

- Breakdown Self Diagnosis function
- System Status Check Buttons for servicing purpose
- System Service Mode Button for servicing purpose
- Front maintenance design for mono bloc unit


• Operation Condition

| | | Water outlet temperature (°C) | Ambient temperature (°C) |
|---------|---------|-------------------------------|--------------------------|
| HEATING | Maximum | 65 | 35 |
| HEATING | Minimum | 25 | -20 |


NOTICE: When the outdoor temperature is out of the above temperature range, the heating capacity will drop significantly and mono bloc unit might stop for protection control.


4. Location of Controls and Components

4.1 Mono Bloc Unit



4.1.1 Main Components





Water pump: The pump circulates the water in the water circuit.

Pressure gauge: The manometer allows read out of the water pressure in the water circuit.

Flow switch: The flow switch checks the flow in the water circuit and protects the heat exchanger

against high pressure built-up and the pump against damage.

Pressure relief valve: The pressure relief valve prevents excessive water pressure in the water circuit

(> 300kPa).


Electric Heater: Additional heating capacity to the system when water and ambient temp is low.

Expansion Vessel: Storage for excessive water.

4.1.2 Location of Control

4.1.2.1 Remote Control

4.1.2.1.1 Remote Control Button



5 System Setting Button

These setting button can change the temperature range of setup setting mode selection.

Perform the steps below to set preferred temperature range.

STEP 1: Press SET button for 5 seconds to enter setting mode.

STEP 2: Press upward or downward button to choose the 7 of the parameter as below for change the temperature range.

1) Low outdoor ambient set temperature

(Selection range: -15°C ~ 15°C).

2) High outdoor ambient set temperature

(Selection range: -15°C ~ 15°C).

 Water outlet set temperature at low outdoor ambient temperature (Selection range: 25°C ~ 65°C).

4) Water outlet set temperature at high outdoor ambient temperature (Selection range: 25°C ~ 65°C).

- 5) Set temperature for turning OFF heating operation (Selection range: 5°C ~ 35°C).
- 6) Outdoor ambient set temperature for turning ON heater operation (Selection range: -15°C ~ 20°C).
- 7) Sanitary tank set temperature (Selection range: 40°C ~ 75°C).
- STEP 3: Press SELECT button to enter selected parameter.
- STEP 4: Press upward or downward button to set the desired temperature.
- STEP 5: Press SET button again to confirm the setting.

Note: Repeat steps 2 to 5 to set other parameters.

STEP 6: Press CANCEL button or wait 30 seconds to exit "SETTING" mode.

Water Temperature Thermo Shift Setting

Perform the steps below to set the desired shift temperature.

STEP 1: Press SET button within 5 seconds.

STEP 2: Press SELECT button to enter the setting temperature.

STEP 3: Press upward or downward button to set desired temperature (Selection range: -5°C ~ 5°C).

STEP 4: Press SET button again to confirm the setting.

STEP 5: Press CANCEL button or wait 30 seconds to exit setting.

(6) Timer Button

This button is to set weekly timer and clock-time combine with setting button.

Perform the steps below to setting the current day and time.

STEP 1: Press CLOCK button.

STEP 2: Press SETTING upward or downward buttons to set current day.

STEP 3: Press SET button to confirm.

STEP 4: Repeat STEP 2 and 3 to set the current time.

Note: The current time that has been set will be the standard time for all the Timer Operations.

(7) Force Button

This button is to select force heater mode operation.

Press OFF/ON button to stop the force heater mode operation.

8 System Service Button

9 System Status Check Button

This button is to check the various mode status.

Perform the steps below to check the selection status.

STEP 1: Press CHECK button for 5 seconds to enter STATUS mode.

STEP 2: Press SEARCH Upward or Downward buttons for checking below value,

1.Compressor running frequency

2. Error history

3. Water inlet temperature


4. Tank Temperature

STEP 3: Press CANCEL button to exit STATUS mode.

(10) Error Reset Button

This button is to reset the remote control and system error code.

4.1.2.1.2 Remote Control Display



(11) Heat Mode OFF/ON Indicator

This icon indicates heating mode operation.

12 Tank Mode Indicator

This icon indicates tank mode operation.

(13) Quiet Mode Indicator

This icon indicates quiet mode operation.

(14) **HEATER** Indicator

This icon indicates backup heater mode operation.

(15) FORCE Indicator

This icon indicates force heater mode operation.

16 Remote Display

This LCD show the external thermo controller connected display.

(17) Operation LED

This LED indicates the unit is in operation.

(18) Solar Display

This LCD show the solar display.

(19) Caution (Tank Temperature above 60°C) Indicator

This LCD show the Caution display.

20 Timer/Clock Setting display

This LCD show the weekly schedule timer setting and clock display.

(21) Outdoor Ambient Temperature Display

This LCD show the outdoor ambient temperature.

22 Water Outlet Temperature Display

This LCD show the water outlet temperature.

(23) **HEATER** indicator

This icon indicates backup heater actual operation.

24 BOOSTER indicator

This icon indicates booster heater actual operation.

25 DEFROST indicator

This icon indicates the system defrost operation request OFF/ON display.

26 System Setting Indicator

This icon indicates the system setting mode request OFF/ON display.

27) System Status Indicator


This icon indicates the status check mode request OFF/ON display.

28 System Service Indicator

This icon indicates the system service mode request OFF/ON display.

4.1.3 **Setting Up The Special Functions**

- After initial installation, you can manually adjust the settings. The initial setting remains active until the user changes it.
- The remote control can be used for multiple installations. Some functions may not be applicable to your unit.
 Ensure the operation LED is in OFF condition before setting.




| Set | Set Remote Control's Display | | Description | |
|-----|------------------------------|-----|---|--|
| 1 | rooii | con | External Thermo Controller (YES / NO) To set external thermo controller connection. | |
| 2 | HEATER | CAP | Backup Heater Capacity Selection (3kW / 6kW / 9kW) To reduce the heater power whenever unnecessary. Options vary depending on model. | |
| 3 | An E , | FrE | Water System Freeze Prevention Function (YES / NO) To activate or deactivate water system freeze prevention function when unit is OFF. | |
| 4 | TANK | con | Tank Connection (YES / NO) To set tank connection. Note: If select "Tank connection" is "NO", Set 5 ~ 14 are skipped. | |
| 5 | SOLAR | Pry | Solar Priority (YES / NO) To choose the solar use for water tank heat up. | |
| 6 | HEAT | Pry | Heating Priority (YES / NO) To choose the room heating as priority during HEAT + TANK mode. Note: If select "Heating priority" is "YES", Set 7 ~ 8 are skipped. | |
| 7 | HEAT | int | Heating operation Interval Set To set timer for Heat mode during HEAT + TANK mode (0.5hour ~ 10 hours). | |
| 8 | TANK | int | Tank Heat-up Interval Set To set timer for Tank during HEAT + TANK mode (5minutes ~ 1hour 35minutes). | |
| 9 | BOOSTER | hbr | Booster Heater Function (YES/NO) To activate or deactivate tank booster heater function. Note: If select "Booster heater function" is "NO", Set 10 is skipped. | |
| 10 | BOOSTER | qra | Booster Heater Delay Timer Set To set delay timer for booster heater to ON if water tank temperature is not reached (20minutes ~ 1hour 35minutes). | |

- Do not use the system during sterilization to prevent scalding or overheat during shower.
- The sterilization function field settings must be configured by the authorized dealer according to local laws and regulation.
- The sterilization set temperature may not achieve if tank booster heater function is deactivated.

| 11 | Strl | Fun | Sterilization (YES/NO) To set sterilization, if required. Note: If select "Sterilization" is "NO", set 12 ~ 14 are skipped. |
|----|------|------|---|
| 12 | Str | | Sterilization Day & Time Set To set timer for sterilization (only once a week, will operate even in standby condition). |
| 13 | Strl | bo 1 | Sterilization Temperature Set To set temperature for sterilization function (40°C ~ 75°C). |
| 14 | Str | oPr | Sterilization Continue Time To set timer to maintain heating temperature in order to complete the sterilization function (5minutes ~ 1hour). |

4.1.4 Weekly Timer Setting




Notes:


- You can set the Timer for each day of the week (Monday to Sunday) with 6 programs per day.
- When the unit is switched on by the ON TIMER, it will use the previously set temperature to control the water outlet temperature.
- · Same timer program cannot be set in the same day.
- · You may also select collective days with same timer setting.
- Promotes energy saving by allowing you to set up to 6 programs in any given day.


5. Dimensions

5.1 Mono Bloc Unit




6. Refrigeration and Water Cycle Diagram






7. Block Diagram

7.1 WH-MHF09D3E8





7.2 WH-MHF12D9E8




8. Wiring Connection Diagram


8.1 WH-MHF09D3E8






8.2 WH-MHF12D9E8







9. Electronic Circuit Diagram


9.1 WH-MHF09D3E8





9.2 WH-MHF12D9E8







10. Printed Circuit Board

10.1 Water system

10.1.1 Main Printed Circuit Board




10.1.2 Solar Printed Circuit Board (Optional)




10.2 Refrigerant System

10.2.1 Main Printed Circuit Board




10.2.1.1 Noise Filter Printed Circuit Board




11. Installation Instruction Mono Bloc Unit

Dimension Diagram



Main Components



Component name

- ① PCB
- 2 Pressure relief valve
- 3 Flow switch
- 4 Pressure gauge
- 5 Water pump
- 6 1 phase RCCB
- 7 3 phase RCCB
- 8 Bushing
- Cabinet front plate
- ① Cabinet top plate
- 11) Overload protector
- 12 Heater assembly
- 13 Expansion vessel
- 14 Cover
- 15 Air purge valve

Connector name

- a Water inletb Water outlet
- It is advisable to avoid more than 2 blockage directions. For better ventilation & multiple-outdoor installation, please consult authorized dealer/specialist.

11.1 Select the Best Location

- Install the Mono bloc unit in outdoor locations only.
- Avoid installations in areas where the ambient temperature may drop below -20°C.
- The Mono bloc unit must be installed on a fl at, solid surface.
- A place removed from any heat source or steam which may affect the operation of the mono bloc unit.
- A place where air circulation is good.
- A place where drainage can be easily done.
- A place where Mono bloc unit's operation noise will not cause discomfort to the user.
- A place which is accessible for maintenance.
- Ensure to keep minimum distance of spaces as illustrated below from wall, ceiling, or other obstacles.
- A place where flammable gas leaking might not
 occur.
- A place where the Mono bloc unit's piping and wiring lengths come within reasonable ranges.
- If an awning is built over the unit to prevent direct sunlight or rain, be careful that heat radiation from the condenser is not obstructed.
- Do not place any obstacles which may cause a short circuit of the discharged air.
- Avoid installing the Mono bloc unit at a location where suction side may be exposed directly to wind.
- If Mono bloc unit installed near sea, region with high content of sulphur or oily location (e.g. machinery oil, etc.), it lifespan maybe shorten.
- When installing the product in a place where it will be affected by typhoon or strong wind such as wind blowing between buildings, including the rooftop of a building and a place where there is no building in surroundings, fix the product with an overturn prevention wire, etc. (Overturn prevention fitting model number: K-KYZP15C)



 When connecting solar pump station cable between Mono bloc unit and solar pump station, the distance between both apparatuses shall be 2 ~ 8 meters and the length of the said cable must be shorter than 10 meter.
 Failure to do so may lead to abnormal operation to the system.

11.2 Mono Bloc Unit Installation

Mono bloc unit will become heavy when filled with water.

Please install the unit on a strong concrete floor and consider the weight of the unit and water.

- Fix Mono bloc unit on the concrete floor with M12 anchor bolt at 4 locations.
- Pull-out strength of these anchor bolts must be above 15000N.




Illustration of grip type and embedded type anchor bolt

11.3 Piping Installation

⚠ WARNING

This section is for authorized and licensed electrician / water system installer only. Work behind the front plate secured by screws must only be carried out under supervision of qualified contractor, installation engineer or service person.


Please engage a licensed water circuit installer to install this water circuit.

- The minimum requirement of water in the system is 50 litres. If this value could not be achieved, please install additional buffer tank (field supply).
- This water circuit must comply with relevant European and national regulations (including EN61770), and local building regulation codes.
- Ensure the components installed in the water circuit could withstand water pressure during operation.
- Do not apply excessive force to piping that may damage the pipes.
- Use Rp 1 ¼" nut for both water inlet and water outlet connection and clean all piping with tap water before connecting to the Mono bloc unit.
- Cover the pipe end to prevent dirt and dust when inserting it through a wall.
- If an existing tank is to be connected to this Mono bloc unit, ensure the pipes are clean before water pipe installation is carried out.
- An external filter (30 mesh or more field supplied) must be installed before the water inlet of the Mono bloc unit (with "WATER IN" indication).


- Refer to Diagram 3.1 for pipe connection of Radiator, Floor Heater, Tank Unit, Solar Pump Station, 3-way Valve Kit and etc. Fail to connect the pipes appropriately might cause the unit malfunction.
- Choose proper sealer which can withstand the pressures and temperatures of the system.
- Make sure to use two spanners to tighten the connection. Further tighten the nuts with torque wrench in specified torque as stated in the table.

| Model | Nut size (Torque) | |
|--------------|-----------------------|--|
| Wiodei | Water | |
| WH-MHF09D3E8 | Do 1 1/4" [117 6 Nam] | |
| WH-MHF12D9E8 | Rp 1 1/4" [117.6 N•m] | |

- If non-brass metallic piping is used for installation, make sure to insulate the piping to prevent galvanic corrosion.
- Do not use pipes that are crushed or deformed. If these inferior pipes are used, it may cause unit malfunction.
- Make sure to insulate the water circuit piping (insulator thickness: 20mm or more) to prevent reduction of heating capacity, as well as avoid freezing of the outdoor water circuit piping during winter season.
- After installation, check the water leakage condition in connection area during test run.



 In case of a power supply failure or pump operating failure, drain the system (as suggested in the figure below).



When water is idle inside the system, freezing up is very likely to happen which could damage the system.

Drainage piping installation

- Use a drain hose with inner diameter of 15 mm.
- The hose must be installed in a continuously downward direction and left open to the frost-free atmosphere.
- If drain hose is long, use a metal support fixture along the way to eliminate the wavy pattern of drain tube.
- Water will drip from this hose, therefore the outlet of this hose must be installed in an area where the outlet cannot become blocked.
- Do not insert this hose into sewage or drain pipe that may generate ammonia gas, sulfuric gas, etc.
- If necessary, use a hose clamp to tighten the hose at drain hose connector to prevent it from leaking.






Illustration of how to fix drain hose to Mono bloc unit

11.4 Connect The Cord And Cable To Mono bloc Unit

(REFER TO WIRING DIAGRAM AT UNIT FOR DETAIL)


- 1 An isolating device must be connected to the power supply cable (Disconnecting means).
 - o Isolating device (Disconnecting means) should have minimum 3.0 mm contact gap.
 - Connect the approved polychloroprene sheathed power supply 1 cord (5 x min 1.5 mm²) and power supply 2 cord (3 x min 1.5 mm²) and power supply 3 cord (5 x min 1.5 mm²), type designation 60245 IEC 57 or heavier cord to the RCCB, and to the other end of the cord to isolating device (Disconnecting means).
- 2 To avoid the cable and cord being damaged by sharp edges, the cable and cord must be passed through a bushing (located at the right hand side of the mono bloc unit) before being connected to the terminal block. The bushing must be used and must not be removed.
- 3 Secure the cable onto the control board with the holder (clamper).






Connecting with external device (optional)

- 1 All connections shall follow to the local national wiring standard.
- 2 It is strongly recommended to use manufacturer-recommended parts and accessories for installation.
- Maximum output power of booster heater shall be \leq 3 kW. Booster Heater cord must be (3 x min 1.5 mm²), of type designation 60245 IEC 57 or heavier.
- 4 Three-way Valve shall be spring and electronic type. Valve cable shall be (3 x min 0.5 mm²), of type designation 60245 IEC 57 or heavier, or similarly double insulation sheathed cable.
 - * note: Shall be CE marking compliance component.
 - It shall be directed to heating mode when it is OFF.
 - Maximum load for the valve is 9.8VA.
- 5 Room Thermostat cable must be (4 or 3 x min 0.5 mm²), double insulation layer of PVC-sheathed or polychloroprene sheathed cable.
- 6 Tank OLP cable must be (2 x min 0.5 mm²), double insulation layer of PVC-sheathed or polychloroprene sheathed cable.
 - * note: if such connection deemed NO necessary for tank OLP, please connect jumper between terminal no.13 and 14.
- 7 Tank Sensor shall be resistance type, please refer to Graph 4.1 for the characteristic and details of sensor. Its cable shall be (2 x min 0.3 mm²), double insulation layer (with insulation strength of min 30V) of PVC-sheathed or polychloroprene sheathed cable.
- 8 External Controller shall be connected to 1-pole switch with min 3.0mm contact gap. (connection refer to Diagram 4.2). Its cable must be (2 x min 0.5 mm²), double insulation layer of PVC-sheathed or polychloroprene sheathed cable.
 - * note: When making such connection, kindly remove the jumper between terminal no.17 and 18.
 - Switch used shall be CE compliance component.
 - Maximum operating current shall be less than 3A_{rms}.
- 9 Must install Solar Connection PCB (optional) to Mono bloc unit when Solar Pump Station is utilized. Refer Solar Connection PCB's installation instruction for detail of installation.
- 10 Solar Three-way Valve cable shall be (3 x min 0.5 mm²), double insulation layer PVC-sheathed or polychloroprene sheathed cable.
- 11 Solar Pump Station cable shall be (2 x min 0.5 mm²), of double insulation PVC-sheathed or polychloroprene sheathed cable. Strongly recommended install with maximum length of 10 meter only.



| Terminal screw | Tightening torque N•cm {kgf•cm} |
|----------------|---------------------------------|
| M4 | 157~196 {16~20} |
| M5 | 196~245 {20~25} |

11.4.1 Wire Stripping And Connecting Requirement



11.4.2 Connecting Requirement

For WH-MHF09D3E8:

- The equipment's power supply 1 complies with IEC/EN 61000-3-2.
- The equipment's power supply 2 complies with IEC/EN 61000-3-2.

For WH-MHF12D9E8:

- The equipment's power supply 1 complies with IEC/EN 61000-3-2.
- The equipment's power supply 2 complies with IEC/EN 61000-3-2.
- The equipment's power supply 3 complies with IEC/EN 61000-3-2.
- The equipment's power supply 3 shall be connected to a suitable supply network, with the following maximum permissible system impedance Z_{max} at the interface of the point for model:

WH-MHF12D9E8: 0.449Ω

Please liaise with supply authority to ensure that the power supply 3 is connected to a supply of the impedance or less.

11.4.3 Wired Remote Controller Installation


| | ⚠ WARNING | | | |
|------------|---|--|--|--|
| \Diamond | Do not modify the length of the remote control cable. Otherwise, it will cause fire or electrical shock. | | | |
| 0 | Be sure to turn off the main power before installing and connecting the remote control. Otherwise, it will cause the electrical shock. | | | |
| 0 | Use the attached accessories parts and specified parts for installation. Otherwise, it will cause the set to fall, fire or electrical shock. | | | |
| 0 | Wire routing must be properly arranged so that control board cover is fixed properly. If control board cover is not fixed properly, it will cause fire or electrical shock. | | | |
| 0 | If passing the remote control cable through a wall, be sure to install a water trap above the cable. Otherwise, it will cause the electrical shock. | | | |
| | ⚠ CAUTION | | | |
| 0 | Install in a flat surface to avoid warping of remote control, else damage to the LCD case or operation problems may result. | | | |
| 0 | Avoid installing the remote control cable near refrigerant pipes or water pipes, else will cause electrical shock or fire. | | | |
| 0 | Install the remote control cable at least 5cm away from electric wires of other appliances to avoid miss operation (electromagnetic noise). | | | |
| • | Be sure to use only the accessory screws to avoid damage of remote control PCB. | | | |


Attached Accessories

| No. | Name | Qty. | Diagram | Remark |
|-----|-----------------------------------|------|---------|---|
| (1) | Remote control | 1 | | |
| (2) | Remote control cable | 1 | | Length (15 m) |
| (3) | Screw (M4 machine pitched - 30mm) | 3 | | Installing the remote control to an outlet box (embedded cable) |
| (4) | Screw (M4 self tapping - 14mm) | 3 | «TITES | Installing the remote control to the wall (exposed cable) |

11.4.3.1 Selecting The Installation Location

- Allow sufficient space around the remote control (1) as shown in the illustration above.
- Install in a place which is away from direct sunlight and high humidity.
- Install in a flat surface to avoid warping of the remote control. If installed to a wall with an uneven surface, damage to the LCD case or operation problems may result.
- Install in a place where the LCD can be easily seen for operation. (Standard height from the floor is 1.2 to 1.5 meters.)
- Avoid installing the remote control cable near refrigerant pipes or drain pipes, else it will cause electrical shock or fire.







11.4.3.2 Installing The Remote Control Unit To The Wall

- 1 Remove the remote control (1) lower case. (Insert a flat-tipped screw driver or similar tool 2 to 3 mm into one of the gaps at the bottom of the case, and twist to open. Refer to the illustration at right.)
 - Be careful not to damage the lower case.
- 2 Do not remove the protective tape which is affixed to the upper case circuit board when removing the remote control lower case.
- 3 Secure the lower case to an outlet box or wall. Refer to (A) or (B) instructions below depending on your choice of cable installation.
- 4 Be sure to use only the screws provided.
- 5 Do not over tighten the screws, as it may result in damage to the lower case.

A. If Remote Control Cable Is Embedded


- 1 Embed an outlet box (JIS C 8336) into the wall. Outlet box may be purchased separately. Medium-sized square outlet box (obtain locally) Part No. DS3744 (Panasonic Co., Ltd.) or equivalent.
- 2 Secure the remote control lower case to the outlet box with the two accessory screws (3). Make sure that the lower case is flat against the wall at this time, with no bending.
- 3 Pass the remote control cable (2) into the box.
- 4 Route the remote control cable (2) inside the lower case through rear feeding-out direction.
- 5 Insert firmly the connector of remote control cable (2) to connector (CON1) in the upper case circuit board. [Refer to the illustration at below.]
- 6 Secure the remote control upper case to the lower case with the tabs provided.






A CAUTION

When the wall is hollow, please be sure to use the sleeve for remote control cable to prevent dangers caused by mice biting the cable.




B. If Remote Control Cable Is Exposed

- 1 Install the remote control lower case to the wall with the two accessory screws (4).
- 2 Fasten the screws properly until screw head is lower than the rib and reach the base of remote control lower case to ensure they do not damage the PCB inside the remote control (1).



3 The feeding-out direction for the remote control cable can be either via top, left or right side.

- 4 Use nipper to cut a notch at the upper case. (Select the intended feeding-out position)
- 5 Route the remote control cable (2) inside the lower case in accordance with the intended feeding-out direction. (Refer to the illustration at below)
- Insert firmly the connector of remote control cable (2) to connector (CON1) in the upper case circuit board. (Refer to the illustration at below)
- 7 Secure the remote control upper case to the lower case with the tabs provided.





11.4.3.3 Connecting The Remote Control Cable To Mono Bloc Unit

⚠ WARNING

Be sure to turn off the main power before installing and connecting the remote control. Otherwise, it will cause the electrical shock.


- 1 Remove the cabinet front plate.
- 2 Connect the remote control cable with the provided connector as shown in below illustration. (Refer wiring diagram for detail.)
- Guide the remote control cable through the clamper and Bushing ①.
 (Refer illustration "How to connect Remote Control to Provided Connector" for detail.)
- 4 Reinstall the cabinet front plate after connection complete.





11.4.3.4 Disposal of Mono Bloc Unit Drain Water

- When a Drain elbow is used, please ensure to follow below:
 - o The unit should be placed on a stand which is taller than 50mm.
 - o Cover the 8 holes (ø20mm) with Rubber cap ② (refer to illustration below)
 - o Use a tray (field supply) when necessary to dispose the Mono bloc unit drain water.



• If the unit is used in an area where temperature falls below 0°C for 2 or 3 consecutive days, it is recommended not to use the Drain elbow 🗓 and Rubber cap 🖾, for the drain water freezes and the fan will not rotate.

12. Operation and Control

12.1 Basic Function

Inverter control, which equipped with a microcomputer in determining the most suitable operating mode as time passes, automatically adjusts output power for maximum comfort always. In order to achieve the suitable operating mode, the microcomputer maintains the set temperature by measuring the temperature of the environment and performing temperature shifting. The compressor at mono bloc unit is operating following the frequency instructed by the microcomputer at indoor unit that judging the condition according to internal water setting temperature and water outlet temperature.

12.1.1 Internal Water Setting Temperature

Once the operation starts, remote control setting temperature will be taken as base value for temperature shifting processes. These shifting processes are depending on the Air-to-Water Heatpump settings and the operation environment. The final shifted value will be used as internal water setting temperature and it is updated continuously whenever the electrical power is supplied to the unit.

12.1.2 Heating Operation

12.1.2.1 Thermostat control

- Compressor is OFF when Water Outlet Temperature Internal Water Setting Temperature > 2°C for continuously 3 minutes.
- Compressor is ON after waiting for 3 minutes, if the Water Outlet Temperature Water Inlet Temperature (temperature at thermostat OFF is triggered) < -3°C.

12.1.3 Tank Mode Operation

Control contents:

- 3 ways valve direction
 - 3 ways valve switch and fix to tank side.
- Heat pump Thermostat characteristic
 - Water set temperature = Tank set temperature or [60°C] whichever lower.
 - Heat pump Water Outlet set temperature is set to Maximum (63°C) at tank mode
- i. Case 1
 - THERMO OFF TEMP:
 - 1 THERMO OFF TEMP = Water set temperature + [0°C].
 - 2 Tank temperature > THERMO OFF TEMP for continuous 10 seconds after heat pump OFF, water pump OFF.
 - THERMO ON TEMP:
 - 1 THERMO ON TEMP = Water set temperature + [-2°C].
 When detect tank temperature < THERMO ON TEMP, water pump ON for 3 minutes then heat pump ON.</p>


ii. Case 2


- Heat pump THERMO OFF TEMP:
 - 1 Heat pump THERMO OFF TEMP = 63°C + [+4°C].
 - 2 Water outlet temperature > Heat pump THERMO OFF TEMP for continuous 3 minutes, heat pump OFF.
- Heat pump THERMO ON TEMP:
 - 1 Heat pump THERMO ON TEMP = Water inlet during thermo off time + [-3°C].
 - 2 Heat pump ON back when water outlet temperature < Heat pump THERMO ON TEMP.</p>


iii. Case 3

- Heat pump THERMO OFF TEMP:
 - 1 Water inlet temperature > 65°C for continuous 60 secs, heat pump OFF.
- Heat pump THERMO ON TEMP:
 - 1 Heat pump THERMO ON TEMP = Water inlet temperature < 65°C.

- Booster heater control
 - Booster heater turn On and Off follow normal operation.
 - Booster heater turn ON condition:
 - 1 During startup time (initialization), Booster heater turn ON after DELAY TIMER.
 - 2 When tank temperature lower than HEATER ON TEMP
 - 3 20 minutes from previous heater off.
 - Booster heater turn OFF condition:
 - 1 When tank temperature higher than tank set temperature for continuous 15 secs.
- Solar 3 way valve
 - Solar pump operates follow solar operation specification.
- 2 way valve closes
- Others
 - Indoor backup heater cannot be ON during tank mode only.







12.1.4 Heat + Tank Mode Operation

Setting 1: When Heating priority is set by remote control:

- 1 3 ways valve control:
 - 3 ways valve switch to room side during External Room Thermo ON OR Solar 3ways valve ON OR Tank
 Thermo OFF time, and switch to tank side at External Room Thermo OFF AND Solar 3 ways valve OFF
- 2 Heat pump operation control:-
 - During External Room Thermo ON time: (When room thermo ON, heat pump must operate to room side)
 - Heat pump operate follow normal operation at room side
 - During External Room Thermo OFF time:
 - Switch 3 ways valve to tank side, IF Under Solar Priority Set condition:
 - Tank temperature < Tank THERMO ON TEMP AND Solar Valve OFF Under Solar Priority Not Set condition:
 - Tank temperature < Tank THERMO ON TEMP

- Switch back 3 ways valve to room side, Heat pump and water pump turn OFF, IF
 - External Room Thermo ON back OR

Under Solar Priority Set condition:

Tank temperature > Tank THERMO OFF TEMP. for continuous 3 minutes OR Solar Valve ON

Under Solar Priority Not Set condition:

- Tank temperature > Tank THERMO OFF TEMP for continuous 3 minutes
- * THERMO ON and THERMO OFF point refer to case below.

Operation condition when 3 ways valve switch to tank side:

- Tank water set temperature = tank set temperature or [60°C] whichever lower
- Heat Pump Water Outlet set temperature is set to [63°C] during tank interval
- Initial Tank THERMO ON TEMP = heat pump tank target temperature + [-2°C]

Case 1:

- THERMO OFF TEMP:
 - 1. THERMO OFF TEMP = Tank water set temperature + [0°C].
 - 2. Tank temperature > THERMO OFF TEMP for continuous 10 seconds after compressor off, switch 3 wavs valve to room side.
- Next THERMO ON TEMP:
 - 1. THERMO ON TEMP = Heat pump tank target temperature + [-2°C] or
 - 2. If tank temperature < THERMO ON TEMP AND External Room Thermo OFF, switch to tank side.

Case 2:

- Heat pump THERMO OFF TEMP:
 - 1. Heat pump THERMO OFF TEMP = 63°C + [+4°C].
 - 2. Water outlet temperature > Heat pump THERMO OFF TEMP for continuous 3 minutes, heat pump OFF.
- Next THERMO ON TEMP:
 - 1. THERMO ON TEMP = Water inlet when heat pump THERMO OFF + [-3°C].
 - 2. If water outlet temperature < THERMO ON TEMP AND External Room Thermo OFF, heat pump ON.

- Heat pump THERMO OFF TEMP:
 - 1. Water inlet temperature > 65°C for continuous 60 secs, heat pump OFF.
- Next THERMO ON TEMP:
 - 1. THERMO ON TEMP = Water inlet temperature < 65°C.
 - 2. If water inlet temperature < THERMO ON TEMP AND External Room Thermo OFF, heat pump ON.


Case 4: (Only during solar priority is set condition)


- When solar request ON, solar valve will ON and switch 3 ways valve to room side
- THERMO ON TEMP:
 - 1. THERMO ON TEMP = Heat pump tank target temperature + [-2°C].
 - 2. If tank temperature < THERMO ON TEMP AND External Room Thermo OFF AND Solar 3WV OFF, switch to tank side.
- Backup Heater control:-
 - During External Room Thermo ON time, follow normal backup heater control operation
 - During External Room Thermo OFF time, Backup heater OFF
- Booster heater control:
 - Booster heater On/Off follow normal operation.
 - * Under solar priority is set condition, when solar 3 way valve is ON, booster heater turn OFF.


5 Solar 3 way valve:

- Solar 3 way valve operates follow solar operation specification.
 - * Under solar priority is set condition, when solar 3WV turn ON, booster heater will turn OFF and 3 ways valve switch to room side.
 - * Under solar priority is not set condition, solar 3WV will OFF when heat pump operate to tank side.

o 2 way valve opens.







Setting 2: When heating priority is not set by remote control:

- When Solar Priority is set / not set by remote control:
 - 1 3 ways valve control:
 - 3 ways valve switch to room side during heating heat-up interval, and switch to tank side during tank heat-up interval. Both mode will switch alternatively. Tank mode is the Initial running mode of this heat + tank mode (heating no priority).
 - 2 Heat pump operation control:
 - During heating heat-up interval
 - Follow normal heating operation.

Under solar priority set condition:

- Switch to tank heat-up interval and start counting tank heat-up timer when External Room Thermo OFF **AND** solar 3WV OFF **AND** Tank temperature < THERMO ON TEMP (End Room Interval Early) **OR**
- Switch to tank heat-up interval and start counting tank heat-up timer when tank temperature < THERMO ON TEMP **AND** solar 3WV OFF

Under solar priority not set condition:

- Switch to tank heat-up interval and start counting tank heat-up timer when External Room Thermo OFF **AND** Tank temperature < THERMO ON TEMP (End Room Interval Early) **OR**
- Switch to tank heat-up interval and start counting tank heat-up timer when tank temperature < THERMO ON TEMP
- * THERMO ON TEMP is defined form following Case1 to Case4.
- During tank heat-up interval
 - Heat pump tank target temperature = Tank set temperature or [60°C] whichever lower
 - Heat pump Water Outlet set temperature is set to Maximum [65°C] during tank interval
 - Initial Tank THERMO ON TEMP = heat pump tank target temperature + [-2°C]

Case 1:

- THERMO OFF TEMP:
 - 1. THERMO OFF TEMP = Heat pump tank target temperature + [0°C].
 - 2. Tank temperature > THERMO OFF TEMP for continuous 10 seconds after heat pump off due to water thermo, switch 3 ways valve to room side. End Tank heat-up interval and start count heating heat-up interval.
- THERMO ON TEMP:
 - 1. THERMO ON TEMP = Heat pump tank target temperature + [-2°C].
 - 2. After Heating heat-up interval, always detect tank temperature. Switch to next tank heat-up interval when tank temperature < THERMO ON TEMP

Case 2:

- Heat pump THERMO OFF TEMP:
 - 1. Heat pump THERMO OFF TEMP = 63°C + [+4°C].
 - 2. Water outlet temperature > Heat pump THERMO OFF TEMP for continuous 3 minutes, heat pump OFF.
- THERMO ON TEMP:
 - 1. THERMO ON TEMP = Water inlet temperature, when heat pump thermo off + [-3°C].

Case 3:

- Heat pump THERMO OFF TEMP:
 - 1. Water inlet temperature > 65°C for continuous 60 secs, heat pump OFF.
- THERMO ON TEMP:
 - 1. THERMO ON TEMP = Water inlet temperature < 65°C.

Case 4 (Only during solar priority is set condition):

- When solar pump ON, tank heat-up interval end early and 3 ways valve switch to room side.
- THERMO ON TEMP:
 - 1. THERMO ON TEMP = Heat pump tank target temperature + [-2°C].
 - 2. After Heating heat-up interval, always detect tank temperature. Switch to next tank heat-up interval when tank temperature < THERMO ON TEMP and solar 3 way valve OFF.

- Tank interval will end and start heating interval timer, IF
 - * When this condition happen at tank side before case 1 thermo-off. 3WV switch to room side compulsory and continue until complete room interval.
 - 1. Tank interval timer finish AND External Room Thermo ON OR
 - 2. Fulfill above Case 1 of thermo off condition.

3 Backup heater control:

- During heating heat up interval.
 - Follow normal backup heater control operation.
- During tank heat-up interval.
 - Backup heater OFF during this interval.


4 Booster heater control:

- During heating heat-up interval.
 - Booster heater ON/OFF according to booster heater operation control.
- During tank heat-up interval.
 - Once switch from heating heat-up interval to tank heat-up interval, turn off the booster heater and start counting the BOOSTER HEATER DELAY TIMER.
 - Booster heater turn ON after BOOSTER HEATER DELAY TIMER fulfill and tank temperature lower than tank set temperature.
 - BOOSTER HEATER DELAY TIMER is clear when switch to heating heat-up interval.


5 Solar 3 way valve:

- Solar 3WV operates follow solar operation specification.
- * Under solar priority is set condition, when solar 3WV is ON, booster heater turn OFF
- Under solar priority is not set condition, solar 3WV only can ON during heating heat-up interval.


6 2 way valve opens.



Under Solar Priority Set Condition:




Under Solar Priority Not Set Condition:



12.1.5 Setting Water Outlet Temperature for Heat Mode

The set temperature define the parameters for the outdoor ambient temperature dependent operation of the unit.
 Where by the internal water setting temperature is determined automatically depending on the outdoor temperature. The colder outdoor temperatures will result in warmer water and vice versa. The user has the possibility to shift up or down the target water temperature by remote control setting.




Change in setting water outlet temperature is updated every 30 minutes.

12.1.5.1 Heating Mode Operation Time Chart

- Operation of heat pump provide heating capacity to room side by hot water through heating panel, floor or fan coil.
 - 1 3 ways valve control:
 - 3 ways valve switch and fix to heating side.
 - 2 Heat pump operate follow normal heating operation.
 - 3 Backup heater operate follow normal operation.
 - 4 Solar 3 way valve operates follow solar operation specification.
 - 5 2 way valve opens.


12.1.6 Water Temperature Thermo Shift Setting

- Switchs are ignored during "PUMPDW" = ON.
- Switchs are ignored during "STATUS" = ON.
- "▲", "▼", "SELECT" switch are ignored if "SETTING" = OFF.
- "CANCEL" switch is ignored if "SETTING" = OFF & "STATUS" = OFF.
- If "SET" Switch pressed for less than 5secs, immediately enter water temperature shift setting mode.
- Once enter this setting mode, "SETTING" display is ON.
 This setting mode is used to easily shift the target water outlet temperature.



12.1.7 Fan Motor Operation


Fan motor is adjusted according to operation condition. It starts when compressor starts operation and it stops 30 seconds after compressor stops operation.



12.2 Water Pump

12.2.1 Water Pump Control

- Once the indoor unit is ON, the water pump will be ON immediately and no error judgement for 9 minutes.
 However, during this 9 minutes operation, if there is any abnormality cause at outdoor or malfunction, the compressor should be OFF immediately and restart delay after 3 minutes.
- The system will start checking on the water flow level after operation start for 9 minutes. If water flow level is
 detected low continuously for 10 secs, the water pump and compressor will be OFF permanently and OFF/ON
 remote control LED will blink (H62 error occurs).
- When error happen, the power has to be reset to clear the error.
- If there is no error indication, The water pump shall be continuously running.
- The water pump will remain ON when compressor OFF due to thermostat OFF setting is reached.



- Pump ON-OFF control
 - a. During operation OFF or water pump stop at Tank Mode
 - b. During ERROR stop
 - c. Water flowing flag = ON
 - d. Outdoor air temperature < 30°C

When above [(a) or (b)] and (c) and (d) conditions fulfilled,

PUMP ON for 4 minutes, and OFF for 55 minutes continuously

When any of below mentioned condition below is achieved, this control is cancelled

- f. Operation = ON (except during water pump stop at tank mode)
- g. Water pump run at tank mode
- h. Change from tank mode to another mode during water pump stop at tank mode
- i. Outdoor air temperature ≥ 32°C
- j. Water inlet temperature < 38°C for 30 minutes continuously

12.2.2 Water Pump Only Operation

- Water pump only circulation can be set from the control panel SERVICE S/W when the operation is in Standby Mode.
- Press the SERVICE S/W for continuous 5sec to enter Service Mode.
- In Service Mode, select Sr:02 and press SET S/W to start water pump only operation.
- Water pump will stop operation when H62 is triggered.
- Press the OFF/ON button to stop the water pump only operation.

12.3 Pump Down Operation

Purpose

Ensure the pump down operation when relocating or disposing of the unit. The pump down operation will extract all refrigerant from the piping into the mono bloc unit.

- Pump down operation control:
 - 1 Press the SERVICE S/W for continuous 5 secs to enter Service mode.
 - 2 In service mode, select Sr:01 and press SET S/W to start Pump Down operation.
 - 3 There will be no Low Pressure error & Freeze prevention judgement during pumpdown operation.
 - 4 3 ways valve will shift to room side.
 - 5 Press the ON/OFF button to stop the unit.

12.4 Flow Switch

12.4.1 Flow Switch Control

- 1 The water flow switch serve as an overload protector that shuts down the unit when the water level is detected to be low.
- 2 Detection is Lo (0V) when there is no water flow, and detection is Hi (5V) when there is water flow.

12.5 Force Heater Mode Operation


The backup heater also serves as backup in case of malfunctioning of the mono bloc unit.

- 1 Make sure the OFF/ON remote control LED is OFF (no operation).
- 2 Press the Force button to start the force heater mode operation.
- 3 During force heater mode, all other operations are not allowed.
- 4 Press OFF/ON button to stop the force heater mode operation.

12.6 Mono Bloc Unit Safety

12.6.1 Mono Bloc Unit Safety Control

- 1 When water pump is ON, the system will start checking flow switch status (ON/OFF).
- 2 If the flow switch ON for 10 seconds, the system will check on the water inlet temperature for 10 seconds. If the water inlet temperature not exceeds 80°C, the water pump shall be continuously running with normal mode.
 - If the water inlet temperature exceeds 80°C for continuously 10 seconds, the water pump will be OFF immediately.
- 3 After water pump OFF for more than 10 minutes, it will be ON back and the indoor unit safety control checking is restarted.



12.7 Auto Restart Control

When the power supply is cut off during the operation of Mono Bloc unit, the compressor will re-operate after power supply resumes.

12.8 Indication Panel

| LED | Operation | |
|-----------|---------------|--|
| Color | Green | |
| Light ON | Operation ON | |
| Light OFF | Operation OFF | |

Note:

• If Operation LED is blinking, there is an abnormality operation occurs.

12.9 Back-Up Heater Control

12.9.1 Electric Heater Control

- Normal Heating Mode
 - o Heater On condition:
 - a. Heater switch is ON
 - b. After Heatpump thermo ON for [30] mins
 - c. After water pump operate [9] mins
 - d. Outdoor air temperature < Outdoor set temperature for heater
 - e. [20] minutes since previous Backup heater Off
 - When heatpump cannot operate due to error happens during normal operation, heater will go into force mode automatic
 - * Heater need to operate during deice operation
 - f. When water outlet temperature < Water set temperature + [-8°C] (check water out temperature before ON heater 3 and check also water out temperature after heater delay timer before ON heater 2 and 1)
 - Heater Stop Condition:
 - a. When outdoor set temperature > outdoor set temperature + [+2°C] for continuous 15 secs OR
 - b. When water out temp> water set temperature + [-2°C] for continuous 15 secs OR
 - c. Heater switch is Off OR
 - d. Heat pump thermo-off or OFF condition


2 Force Heater Mode

- Heater On Condition:
 - a. After water pump operate [9] mins
 - b. When water outlet temperature < water set temperature + 1-8°C1
 - c. [20] minutes since previous Backup heater Off
- Heater Stop condition
 - a. Force mode off OR
 - b. When water outlet temperature > water set temperature + [-2°C] for continuous 15 secs
- * Do not operate heater at the following situation
- 1 Water outlet temperature sensor, and water inlet sensor abnormal
- 2 Flow switch abnormal
- 3 Circulation pump stop condition
- 4 During Heatpump switch to tank side

12.10 Tank Booster Heater Control

12.10.1 Tank Booster Heater Control

Heating operation condition:




- 1 Booster heater Turn On condition:
 - After BOOSTER HEATER DELAY TIMER fulfill during heat pump startup time in tank mode, or during switching from heating heat-up interval to tank heat-up interval in heat + tank mode (heating priority not set).
 - Tank temperature < Tank set temperature + [-7°C],
 - 20 minutes since previous heater off.
 - * BOOSTER HEATER DELAY TIMER is clear when tank heat-up interval end.


- 2 Booster heater Turn Off condition:
 - o Tank temperature > Tank set temperature + [0°C] for continuous 15 secs
 - When BOOSTER HEATER DELAY TIMER start count after switch from heating heat-up interval to tank heat-up interval
 - * DELAY TIMER can be set by remote control.

12.11 Base Pan Heater Control (Optional)

To enable the base pan heater function, pin 3 of SW2 of water system PCB has to be switched from OFF to ON position.



- Base pan heater ON condition:
 - o When outdoor ambient temperature ≤ 3°C AND
 - Deice operation ON
 Base pan heater will continue ON for 10 minutes after deice operation ends.
- Base pan heater OFF condition:
 - When outdoor ambient temperature > 3°C OR
 - When operation is not heating OR
 - o Base pan heater ON timer count completed



12.12 Three Way Valve Control

- Purpose:
 - 3 ways valve is used to change flow direction of hot water from heat pump between heating side and tank side
- Control contents:
 - 1 3 ways valve switch Off:
 - During 3 ways valve switch Off time, the hot water will provide heat capacity to heating side.
 - 2 3 ways valve switch On:
 - During 3 ways valve switch On time, the hot water will provide heat capacity to tank side.
 - 3 Stop condition:
 - During stop mode, 3 ways valve will be in switch off position

12.13 Sterillization Mode

- Purpose:
 - o Boil tank temperature to customer set boiling temperature to operate sterilization.
- Control start condition:
 - o Tank connection set to YES by remote controlller
 - Serilization function selection is YES
 - Sterilization signal received from remote controller by timer.
- Control stop condition:
 - After boiling timer completed. Boiling timer start counting once tank achieve boiling set temperature OR
 - After 4 hours of operation since sterilization function start OR
- Control content:
 - Once the sterilization function enable, set the target tank temperature to Boiling Set Temperature.
 - Booster heater will allow to ON during solar priority SET condition.
 - Booster heater OFF Temp. = Boiling Set Temperature 0°C
 - Booster heater ON Temp. = Boiling Set Temperature 7°C
 - o The sterilization set temperature may not achieve if tank booster heater function is deactivated.
 - o Boiling timer which set by remote controller will start count after tank achieve boiling set temperature.
 - Sterilization operation will end after complete boiling timer or Max 4 hrs from function start.
 - o Target tank temperature will set back to normal tank set temperature.

12.14 Quiet Operation

- Purpose:
 - To provide quiet operation compare to normal operation by reduces mono bloc unit noise.
- Starting condition:
 - 1 When quiet button is presses.
 - 2 When quiet request ON time by weekly timer (Refer to remote control.)
- When any of above mentioned condition is achieved, this control is activated.

New target FM speed = Present target FM speed - 80 rpm

Minimum target FM speed = 200 rpm

- Cancellation condition:
 - 1 Cancel by press quiet button
 - 2 Stop by OFF/ON button
 - 3 When quiet request OFF time by weekly timer

When any of above mentioned condition is achieved, this control is cancelled.

12.15 Anti Freeze Control

- Anti freeze protection control can be select YES or NO from control panel. Default setting is YES.
- In heatpump system, there are 2 types of anti freeze control:
 - 1. Water pump circulation anti frost control
 - Water pump turns ON when **ALL** the below conditions are fulfilled:
 - o Heatpump OFF (standby) OR water pump stop (Tank Mode) OR error occurs
 - Water flow switch is not abnormal
 - Outdoor ambient temp. < 3°C
 - Water inlet/outlet temp. < 6°C
 - After 5 minutes from previous water pump OFF
 - Water pump turns OFF when <u>ANY</u> of the below conditions is fulfilled:
 - Outdoor ambient temp. ≥ 4°C
 - During -5°C < outdoor ambient temp. < 4°C
 - After water pump ON for 4 minutes, and water inlet/outlet temp. ≥ 8°C
 - Else, shift to backup heater anti freeze control
 - During outdoor ambient temp. < -5°C
 - After water pump ON for 4 minutes, and water inlet/outlet temp. ≥ 20°C
 - Else, shift to backup heater anti freeze control
 - However, if flow switch is abnormal (H62), then water pump circulation anti freeze control will not activate.


^{*} Tank heater control is not affected by solar pump when solar priority set.

- 2. Backup heater anti freeze control:
 - Backup heater turns ON when **ALL** the below conditions are fulfilled:
 - Water inlet/outlet temp. < 6°C</p>
 - o Water pump circulation anti freeze control activated, and water pump ON for 4 minutes
 - Backup heater turns OFF when <u>ANY</u> of the below conditions is fulfilled:
 - o Water inlet/outlet temp. > 28°C
 - Water pump circulation anti freeze control deactivated/water pump OFF
 - However, if backup heater is abnormal (H70), then backup heater anti freeze control will not activate.

12.16 Solar Operation (Optional)

12.16.1 Solar Operation

- 1 External solar heat source signal can be connect to unit for proper control of heat source switching during tank boiling time.
- 2 Control according to preset whether solar priority is set or not.
- 3 When tank connection is NOT set at SETTING mode, solar operation is disabled.
- When Pump A (from solar pump station) is detected On through connection Y3 and Y4, then the Solar pump 3 Way Valve is requested ON (Refer to figure below).



12.16.2 Solar Operation Control

When solar priority is SET


- 1 Operation condition:
 - 3 way valve operates if all of the following conditions are fulfilled:
 - Power On. (regardless operation ON or OFF)
 - There is operation request from solar pump station.
 - Tank hot water temp is below solar on upper limit temp 72°C.
- 2 Stop condition:
 - a 3 way valve stops operating when:
 - No power supply to unit **OR**
 - There is **NO** operation request from solar pump station **OR**
 - Tank hot water temp is above solar off upper limit temp 80°C.
 - * heat pump OFF OR operate to room side when solar pump operate during solar priority set.
 - * booster heater OFF when solar pump operate during solar priority set.


When solar priority is NOT SET

- 1 Operation condition:
 - a 3 way valve operates if all of the following conditions are fulfilled:
 - Power On. (regardless operation ON or OFF).
 - There is operation request from solar pump station.
 - Tank hot water temp is below solar on upper limit temp 72°C.
 - Heat pump thermo OFF in tank mode OR Heat pump operate to room side (during operation ON and tank mode selected).


2 Stop condition:

- a 3 way valve stops operating when:
 - No power supply to unit OR
 - There is **NO** operation request from solar pump station **OR**
 - Tank hot water temp is above solar off upper limit temp 80°C.
 - Heat pump thermo ON and operate to tank side. (during operation ON and tank mode selected).






Tank Mode [Solar priority SET condition]



Tank Mode [Solar priority NOT SET condition]



12.17 External Room Thermostat Control (Optional)

Purpose:


1 Better room temperature control to fulfill different temperature request by external room thermostat. Recommended external room thermostat:

| Maker | Characteristic |
|-----------------|----------------|
| Siemen (REV200) | Touch panel |
| Siemen (RAA20) | Analog |

Connection external room thermostat:


Wire Connection and thermo characteristic of Siemen REV200:

| Setting | L/L1 (H) | Heat Thermo | L/L2 (C) | Cool Thermo |
|------------------------|---------------|-------------|---------------|-------------|
| Set Temp < Actual Temp | Open Circuit | OFF | Short Circuit | ON |
| Set Temp > Actual Temp | Short Circuit | ON | Open Circuit | OFF |



Wire Connection and thermo characteristic of Siemen RAA20:

| Setting | L/Y1 (H) | Heat Thermo | L/Y2 (C) | Cool Thermo |
|------------------------|---------------|-------------|---------------|-------------|
| Set Temp < Actual Temp | Open Circuit | OFF | Short Circuit | ON |
| Set Temp > Actual Temp | Short Circuit | ON | Open Circuit | OFF |



Control Content:

- External room thermostat control activate only when remote thermostat connection select YES by Indoor remote control.
- When indoor running heat mode, refer thermo On/Off from heating line feedback. And when indoor running cool mode, refer thermo On/Off from cooling line feedback.
- Heat pump Off immediately when receive thermo off feedback.

13. Protection Control

13.1 Protection Control for All Operations

13.1.1 Time Delay Safety Control

1 The compressor will not start for three minutes after stop of operation.

13.1.2 30 Seconds Forced Operation

- 1 Once the compressor starts operation, it will not stop its operation for 30 seconds.
- 2 However, it can be stopped using remote control at indoor unit.

13.1.3 Total Running Current Control

- 1 When the outdoor running current exceeds X value, the compressor frequency will decrease.
- 2 If the outdoor running current does not exceed X value, the compressor frequency will return to normal operating frequency.
- If the outdoor running current continue to increase till exceed Y value, compressor will stop, and if this occurs 3 times within 20 minutes, system will stop operation and OFF/ON remote control LED will blink (F16 error occurs).


| | MHF0 | 9D3E8 | MHF1: | 2D9E8 |
|----------------|-------------|-------|-------|-------|
| Operation Mode | X (A) Y (A) | | X (A) | Y (A) |
| Heating | 9.5 | 12.5 | 10.0 | 12.5 |

13.1.4 IPM (Power Transistor) Prevention Control

- A. Overheating Prevention Control
- 1 When the IPM temperature rises to 95°C, compressor will stop immediately.
- 2 Compressor will restart delay 3 minutes when the IPM temperature decreases to 90°C. If this condition repeats continuously 3 times within 30 minutes, system will stop operation and OFF/ON remote control LED will blink (F22 error occurs).
- B. DC Peak Current Control
- 1 When the current to IPM exceeds set value of 53.5 ± 5.0 A, compressor will stop. Compressor will restart after three minutes.
- 2 If the set value exceeds again for more than 30 seconds after the compressor restarts, operation will restart after two minutes.
- If the set value exceeds again for within 30 seconds after the compressor restarts, operation will restart after one minute. If this condition repeats continuously for seven times, system will stop operation and OFF/ON remote control LED will blink (F23 error occurs).

13.1.5 Compressor Overheating Prevention Control

 The compressor operating frequency is regulated in accordance to compressor tank temperature as shown in below figures. When the compressor tank temperature exceeds 112°C, compressor will stop, and if this occurs 4 times within 30 minutes, system will stop operation and OFF/ON remote control LED will blink (F20 error occurs).




13.1.6 Low Pressure Protection Control

- Purpose:
 - o To protect the system operation.
- Detection period:
 - After compressor on for 5 minutes.
- Detection conditions:
 - When detection of Tem above 30°C.
 - o Calculation of average evaporation temperature (Tem).
 - Use outdoor low pressure sensor.
 - o Tem use the value calculated for discharge temperature setting value
- After detection:
 - Compressor stops restart again after 3 mins.
 - When abnormalities continuously generated 60 times within 480 minutes
 - Protection is prohibited.
 - o Error H42 will be displayed.

13.1.7 High Pressure Sensor Control / Low Pressure Sensor

- Purpose:
 - o To protect the system operation.
- Detection period:
 - o After compressor on for 1 minute.
- Detection conditions:
 - When abnormal high voltage detection, 5V or when open circuit detection 0V for 5 seconds continuously.
- After detection:
 - o When abnormality is detected continue 5 seconds, unit stop operation.
 - o OFF/ON remote control LED will blink (H64 error occurs).

13.1.8 Outside Temperature Current Control



13.1.9 Extreme Low Temperature Control

- Purpose:
 - To improve the compressor reliability during cold start and after deice when running in extreme low outdoor temperature -20°C.
- Starting condition:
 - Heating operation
 - Outdoor air temperature < -10°C
 - o Actual frequency ≥ 50Hz
 - Compressor discharge temperature < 20°C

When the above condition is fulfilled, this control is activated.

5Hz up every 30 sec. until it reaches the target frequency.

- Cancellation condition:
 - starting condition not fulfill.
 - o Cancel the extreme low temperature control when compressor discharge sensor ≥ 60°C

13.1.10 Crank Case Heater Control

- Purpose:
 - For compressor protection during low outdoor ambient operation (during heating low temperature operation).
- Control content:
 - a. Trigger heater START condition
 - When the outdoor air temperature is 4°C or below, and discharge temperature is 12°C or below.
 - Resetting heater STOP condition
 - 1. when the outdoor air temperature 6°C.
 - 2. when the discharge temperature 19°C.


13.2 Protection Control for Heating Operation

13.2.1 Outdoor Air Temperature Control

The maximum current value is regulated when the outdoor air temperature rises above 14°C in order to avoid compressor overloading.

13.2.2 Deice Operation

When outdoor pipe temperature and outdoor air temperature is low, deice operation start where outdoor fan motor stop.



13.2.3 Heat-exchanger (hot water coil) protection control

- Backup heater ON condition:-
 - water inlet temperature < 23°C AND
 - outdoor ambient temperature < 10°C
- Backup heater OFF condition:
 - water inlet temperature > 25°C OR
 - outdoor ambient temperature > 13°C

14. Servicing Mode

14.1 Test Run


- 1 Fill up the Tank Unit with water. For details refer to Tank Unit installation instruction and operation instruction.
- 2 Antifreeze agent must be added into water circuit to prevent freezing of water when outdoor ambient temperatures is low. Recommended antifreeze: Propylene glycol: 40% (equivalent to -20°C)
- 3 Set ON to the Mono bloc unit and RCCB. Then, for remote control operation please refers to (Mono bloc) Airto-Water Heatpump's operation instruction.
- For normal operation, pressure gauge reading should be in between 0.05 MPa and 0.3 MPa. If necessary, adjust the water pump speed accordingly to obtain normal water pressure operating range. If adjust water pump speed cannot solve the problem, contact your local authorized dealer.
- 5 After test run, please clean the external filter. Reinstall it after finish cleaning.

14.2 Proper Pump Down Procedure

- Strictly follow the steps below for proper pump down procedure. Explosion may occur if the steps are not followed as per sequence.
 - 1 Press the "SERVICE" switch on remote control to enter SERVICE mode. Operate the system in Sr : 01 mode for pump down operation.
 - 2 After 10~15 minutes, (after 1 or 2 minutes in case very low ambient temperatures (< 10°C)), fully close 2 way valve.
 - 3 After 3 minutes, fully close 3 way valve.
 - 4 Press the "OFF/ON" switch on remote control to stop pump down operation.
 - 5 Remove the refrigerant piping.

14.2.1 How to Adjust Water Flow Rate

- Before adjust the water flow rate, make sure that the total water volume in the installation is 50 litres minimum.
- The water flow rate can be adjusted with select the water pump speed on the water pump. The default setting is
 medium speed (II). However, please ensure the minimum flow rate cannot be less than 18L/min.
 Adjust it to high speed (III) or slow speed (I) if necessary (e.g. reduce the noise of running water).
 Below graph shown the external static pressure (kPa) versus water flow rate (L/min).



• Flow rate characteristic of mono bloc unit is as per above mentioned.

14.3 Expansion Vessel Pre Pressure Checking

- Expansion Vessel with 10L air capacity and initial pressure of 1 bar is installed in this mono bloc unit.
- Total amount of water in system should be below 200L.
 (Note: This amount of water is not include the tank unit volume)
- If total amount of water is more than 200L, please install additional expansion vessel (field supply).
- Please keep the installation height difference of system water circuit within 10m.
 (Inner volume of same Mono bloc unit is about 5L)

15. Maintenance Guide

In order to ensure optimal performance of the unit, checks and inspections on the unit and the field wiring must be carried out regularly. Please request a licensed technician for carry out maintenance job.


Before carried out any maintenance or repair work, and removing the front plate of heat exchanger unit, always switch off all power supply (i.e. mono bloc unit power supply, heater power supply and sanitary tank power supply). Below checks must be carried out at least once a year.

1 Water pressure

Water pressure should not lower than 0.05 MPa (with inspects the pressure gauge). If necessary add tap water into tank unit. Refer to tank unit installation instruction for details on how to add water.

2 Pressure relief valve


- Take out the cover with remove the mounting screw for access to the pressure relief valve.
- Check for correction operation of pressure relief valve by turn up the lever to become horizontal. (Refer to figure of "Pressure relief valve")
- o If you do not hear a clacking sound (due to water drainage), contact your local authorized dealer.
- Turn down the lever after checking finish.
- In case the water keeps drained out from the unit, switch off the system, and then contact your local authorized dealer.
- Reinstall the cover with tighten the mounting screws properly, if the pressure relief valve is functioning normal.



3 Air purge valve

Air purge valve must be installed at all high points in a closed water circuit system.

An automatic air purge valve is provided inside the indoor unit. To automatically purge the air from the system, turn the plug on the air outlet anticlockwise by one complete turn from fully closed position. Excessive air is automatically purged if the plug is kept in this position.



4 RCCB

Ensure the RCCB set to "ON" condition before check RCCB.

Turn on the power supply to the Mono bloc unit.

This testing could only be done when power is supplied to the Mono bloc unit.



Be careful not to touch parts other than RCCB test button when the power is supplied to Mono bloc unit. Else, electrical shock may happen.

- o Push the "TEST" button on the RCCB. The lever would turn down and indicate "0", if it functions normal.
- o Contact authorized dealer if the RCCB malfunction.
- o Turn off the power supply to the Mono bloc unit.
- o If RCCB functions normal, set the lever to "ON" again after testing finish.

5 Reset overload protector

Overload Protector serves the safety purpose to prevent the water over heating. When the Overload Protector trip at high water temperature, take below steps to reset it.

- o Take out OLP Cover.
- o Use a test pen to push the centre button gently in order to reset the Overload protector.
- Fix the OLP Cover to the original fixing condition.




How to reset Overload protector

6 External water filter (field supply)

Clean the external water filter in regularly basic.

- External water filter is located inside the tube connector which is before water inlet connector of mono bloc unit (indicated with "WATER IN"). (Refer to figure below)
- Use spanner to detach the tube connector nut.
- o Take out the filter carefully so that not deforms it shape.
- Use tap water only to wash the residue on the filter. If necessary, gently use soft brush only to clean the hard dirt.
- o After clean, put it back to the original location and tighten the nut connection with torque wrench.



Troubleshooting Guide

16.1 Refrigeration Cycle System


In order to diagnose malfunctions, make sure that there are no electrical problems before inspecting the refrigeration cycle.

Such problems include insufficient insulation, problem with the power source, malfunction of a compressor and a

The normal pressure of the refrigeration cycle depends on various conditions, the standard values for them are shown in the table on the right.

| ١ | Normal Pressure (Standard) | | | |
|---|-------------------------------|---------------------|--|--|
| | Gas pressure MPa (kg/cm²G) | | | |
| | Heating Mode | 1.4 ~ 1.8 (14 ~ 18) | | |

- ★ Condition: Outdoor temperature 7°C at heating mode.
 - · Compressor operates at rated frequency.
 Water outlet temperature
 - 35°C at heating mode.



16.2 Relationship Between The Condition Of The Mono Bloc Unit And Pressure And Electric Current

| | Heating Mode | | | | |
|--|--------------|---------------|-----------------------------------|--|--|
| Condition of the Mono Bloc Unit | Low Pressure | High Pressure | Electric current during operation | | |
| Water leakage or insufficient water flow rate in the system | * | | | | |
| Excessive amount of refrigerant | | | | | |
| Inefficient compression | - | 1 | * | | |
| Insufficient refrigerant (gas leakage) | * | 1 | * | | |
| Mono Bloc unit (refrigerant system) heat exchange deficiency | * | 1 | | | |
| Clogged expansion valve or Strainer | • | | | | |

Carry out the measurements of pressure, electric current, and temperature fifteen minutes after an operation is started.

16.3 Breakdown Self Diagnosis Function

16.3.1 Self Diagnosis Function (Three Digits Alphanumeric Code)

- When abnormality occur during operation, the system will stop operation, and OFF/ON remote control LED will blink and error code will display on the remote control Timer display LCD.
- Even error code is reset by turning OFF power supply or by pressing ERROR RESET button, if the system abnormality is still un-repaired, system will again stop operation, and OFF/ON remote control LED will again blink.
- The error code will store in IC memory.

To check the error code


- 1 When an abnormality occurs, system will stop operation and OFF/ON remote control LED will blink.
- 2 Error code of the abnormality will display on the remote control Timer display LCD.
- 3 To determine the abnormality description, the Error Code Table needs to be referred.

To display past/last error code

- 1 Turn ON power supply.
- 2 Press and hold the CHECK button for more than 5 seconds to enter status mode.
- 3 Press the SEARCH DOWN/UP button to retrieve past/last error code.
- 4 Press the CANCEL button or wait 30 seconds to exit status mode.

To permanently delete error code from IC memory

- 1 Turn ON power supply.
- 2 Press and hold the ERROR RESET button for more than 8 seconds till a beep sound is heard.



16.4 Error Codes Table

| iagnosis display | Abnormality/Protection control | Abnormality Judgement | Primary location to verify |
|------------------|--|--------------------------------------|---|
| H00 | No abnormality detected | _ | |
| H12 | Indoor/Outdoor capacity unmatched | 90s after power supply | Indoor/outdoor connection wire Indoor/outdoor PCB Specification and combination table in catalogue |
| H15 | Outdoor compressor temperature sensor abnormality | Continue for 5 sec. | Compressor temperature sensor (defective or disconnected) |
| H23 | Indoor refrigerant liquid temperature sensor abnormality | Continue for 5 sec. | Refrigerant liquid temperature sensor (defective or disconnected) |
| H42 | Compressor low pressure abnormality | _ | Outdoor pipe temperature sensor Clogged expansion valve or strainer Insufficient refrigerant Outdoor PCB Compressor |
| H62 | Water flow switch abnormality | Continue for 1 min. | Water flow switch |
| H63 | Refrigerant low pressure abnormality | 4 times occurrence within 20 minutes | Outdoor low pressure sensor (defective or disconnected) |
| H64 | Refrigerant high pressure abnormality | Continue for 5 sec. | Outdoor high pressure sensor (defective or disconnected) |
| H70 | Back-up heater OLP abnormality | Continue for 60 sec. | Back-up heater OLP (Disconnection or activated) |
| H72 | Tank sensor abnormal | Continue for 5 sec. | Tank sensor |
| H76 | Indoor - remote control communication abnormality | _ | Indoor - control panel (defective or disconnected) |
| H90 | Indoor/outdoor abnormal communication | > 1 min after starting operation | Internal/external cable connections Indoor/Outdoor PCB |
| H91 | Tank heater OLP abnormality | Continue for 60 sec. | Tank heater OLP (Disconnection or activated) |
| H95 | Indoor/Outdoor wrong connection | _ | Indoor/Outdoor supply voltage |
| H98 | Outdoor high pressure overload protection | _ | Outdoor high pressure sensor Water pump or water leakage Clogged expansion valve or strainer Excess refrigerant Outdoor PCB |
| H99 | Indoor heat exchanger freeze prevention | _ | Indoor heat exchanger Refrigerant shortage |
| F12 | Pressure switch activate | 4 times occurrence within 20 minutes | Pressure switch |
| F14 | Outdoor compressor abnormal revolution | 4 times occurrence within 20 minutes | Outdoor compressor |
| F15 | Outdoor fan motor lock abnormality | 2 times occurrence within 30 minutes | Outdoor PCBOutdoor fan motor |
| F16 | Total running current protection | 3 times occurrence within 20 minutes | Excess refrigerantOutdoor PCB |
| F20 | Outdoor compressor overheating protection | 4 times occurrence within 30 minutes | Compressor tank temperature senso Clogged expansion valve or strainer Insufficient refrigerant Outdoor PCB Compressor |
| F22 | IPM (power transistor) overheating protection | 3 times occurrence within 30 minutes | Improper heat exchangeIPM (Power transistor) |
| F23 | Outdoor Direct Current (DC) peak detection | 7 times occurrence continuously | Outdoor PCB Compressor |
| F24 | Refrigeration cycle abnormality | 2 times occurrence within 20 minutes | Insufficient refrigerant Outdoor PCB Compressor low compression |
| F25 | Cooling/Heating cycle changeover abnormality | 4 times occurrence within 30 minutes | 4-way valve V-coil |
| F27 | Pressure switch abnormality | Continue for 1 min. | Pressure switch |
| F36 | Outdoor air temperature sensor abnormality | Continue for 5 sec. | Outdoor air temperature sensor (defective or disconnected) |
| F37 | Indoor water inlet temperature sensor abnormality | Continue for 5 sec. | Water inlet temperature sensor (defective or disconnected) |
| F40 | Outdoor discharge pipe temperature sensor abnormality | Continue for 5 sec. | Outdoor discharge pipe temperature sensor (defective or disconnected) |
| F41 | PFC control | 4 times occurrence within 10 | Voltage at PFC |

| Diagnosis display | Abnormality/Protection control | Abnormality Judgement | Primary location to verify |
|-------------------|---|-----------------------|---|
| F42 | Outdoor heat exchanger temperature sensor abnormality | Continue for 5 sec. | Outdoor heat exchanger temperature sensor (defective or disconnected) |
| F43 | Outdoor defrost sensor abnormality | Continue for 5 sec. | Outdoor defrost sensor (defective or disconnected) |
| F45 | Indoor water outlet temperature sensor abnormality | Continue for 5 sec. | Water outlet temperature sensor (defective or disconnected) |
| F46 | Outdoor Current Transformer open circuit | _ | Insufficient refrigerant Outdoor PCB Compressor low |
| F48 | Outdoor EVA outlet temperature sensor abnormality | Continue for 5 sec. | Outdoor EVA outlet temperature sensor (defective or disconnected) |
| F49 | Outdoor bypass outlet temperature sensor abnormality | Continue for 5 sec. | Outdoor bypass outlet temperature sensor (defective or disconnected) |
| F95 | Cooling high pressure overload protection | - | Outdoor high pressure sensor Water pump or water leakage Clogged expansion valve or strainer Excess refrigerant Outdoor PCB |

16.5 Self-diagnosis Method

16.5.1 Connection Capability Rank Abnormality (H12)

Malfunction Decision Conditions:

During startup operation of heating, the capability rank of indoor checked by the outdoor is used to determine connection capability rank abnormality.


Malfunction Caused:

- 1 Wrong model interconnected.
- 2 Wrong indoor unit or outdoor unit PCB (main) used.
- 3 Faulty indoor unit or outdoor unit PCB (main).

Abnormality Judgment:

Continue for 90 seconds.

Troubleshooting:



16.5.2 Compressor Tank Temperature Sensor Abnormality (H15)

Malfunction Decision Conditions:

During startup and operation of heating, the temperatures detected by the compressor tank temperature sensor are used to determine sensor error.


Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 5 seconds.

Troubleshooting:



16.5.3 Indoor Refrigerant Liquid Temperature Sensor Abnormality (H23)


Malfunction Decision Conditions:

During startup and operation of heating, the temperatures detected by the indoor refrigerant liquid temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB (main).

Abnormality Judgment:




16.5.4 Compressor Low Pressure Protection (H42)

Malfunction Decision Conditions:

During operation of heating and after 5 minutes compressor ON, when outdoor pipe temperature below -29°C or above 26°C is detected by the outdoor pipe temperature sensor.

Malfunction Caused:

- 1 Dust accumulation on the outdoor unit heat exchanger.
- 2 Air short circuit at outdoor unit.
- 3 2 way valve partially closed.
- 4 Faulty outdoor unit fan motor.
- 5 Refrigerant shortage (refrigerant leakage).
- 6 Clogged expansion valve or strainer.
- 7 Faulty outdoor pipe temperature sensor.
- 8 Faulty outdoor unit main PCB (main).



16.5.5 Water Flow Switch Abnormality (H62)

Malfunction Decision Conditions:


During operation of heating, the water flow detected by the indoor water flow switch is used to determine water flow error.

Malfunction Caused:

- 1 Faulty water pump.
- 2 Water leak in system.
- 3 Faulty connector connection.
- 4 Faulty water flow switch.
- 5 Faulty indoor unit PCB (main).

Abnormality Judgment:

Continue for 10 seconds (but no judgment for 9 minutes after compressor startup/restart).



16.5.6 Outdoor Low Pressure Abnormality (H63)

Malfunction Decision Conditions:


During operation of heating, when the outdoor low pressure sensor output signal is 0Vdc or 5Vdc.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue 4 times in 20 minutes.



16.5.7 Outdoor High Pressure Abnormality (H64)

Malfunction Decision Conditions:


During operation of heating, when the outdoor high pressure sensor output signal is 0Vdc or 5Vdc.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue 4 times in 20 minutes.



16.5.8 Indoor Backup Heater OLP Abnormality (H70)


Malfunction Decision Conditions:

During operation of indoor backup heater, when no power supplies to indoor backup heater or OLP open circuit.

Malfunction Caused:

- 1 Faulty power supply connector connection.
- 2 Faulty connector connection.
- 3 Faulty indoor backup heater overload protector (OLP).
- 4 Faulty indoor unit PCB (main).

Abnormality Judgment:



16.5.9 Tank Temperature Sensor Abnormality (H72)


Malfunction Decision Conditions:

When tank connection is set to ON, the temperatures detected by the tank temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB (main).

Abnormality Judgment:



16.5.10 Indoor-Control Panel Communication Abnormality (H76)

Malfunction Decision Conditions:

During standby and operation of heating, indoor-remote control error occur.


Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty remote control.
- 3 Faulty indoor unit PCB (main).

Troubleshooting:



For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



16.5.11 Indoor/Outdoor Abnormal Communication (H90)

Malfunction Decision Conditions:

During operation of heating, the data received from outdoor unit in indoor unit signal transmission is checked whether it is normal.

Malfunction Caused:

- 1 Faulty outdoor unit PCB (main).
- 2 Faulty indoor unit PCB (main).
- 3 Indoor-outdoor signal transmission error due to wrong wiring.
- 4 Indoor-outdoor signal transmission error due to breaking of wire in the connection wires between the indoor and outdoor units.
- 5 Indoor-outdoor signal transmission error due to disturbed power supply waveform.

Abnormality Judgment:

Continue for 1 minute after operation.

For safety reason and to prevent component breakdown, **Troubleshooting:** always switch off the power before remove and connect the component. Check the indoor-outdoor units connection wires. Yes Correct the indoor-outdoor Is there any wiring error? units connection wires. No Turn OFF the power and disconnect terminal 3 wire. Turn ON the power and measure Vdc between terminal 2 & 3 from the outdoor unit. Nο Is the Vdc fluctuate Replace the outdoor unit between 45-60Vdc? PCB (main). Yes Turn OFF the power and reconnect terminal 3 wire. Turn ON the power and again measure Vdc between terminal 2 & 3 from the outdoor unit. Nο Is the Vdc fluctuate Replace the indoor unit between 15-60Vdc? PCB (main).

16.5.12 Tank Booster Heater OLP Abnormality (H91)


Malfunction Decision Conditions:

During operation of tank booster heater, and tank booster heater OLP open circuit.

Malfunction Caused:

- Faulty connector connection.
- 2 Faulty tank booster heater overload protector (OLP).
- 3 Faulty indoor unit PCB (main).

Abnormality Judgment:




16.5.13 Unspecified Voltage between Indoor and Outdoor (H95)

Malfunction Decision Conditions:

The supply power is detected for its requirement by the indoor/outdoor transmission.

Malfunction Caused:

- 1 Insufficient power supply.
- 2 Faulty outdoor unit PCB (noise filter/main).




16.5.14 Outdoor High Pressure Protection (H98)

Malfunction Decision Conditions:

During operation of heating, when pressure 4.0 MPa and above is detected by outdoor high pressure sensor.

Malfunction Caused:

- 1 Faulty water pump.
- 2 Insufficient water flow rate in system.
- 3 Water leak in system.
- 4 2/3 way closed.
- 5 Clogged expansion valve or strainer.
- 6 Excessive refrigerant.
- 7 Faulty outdoor high pressure sensor.
- 8 Faulty outdoor unit PCB (main).



16.5.15 Indoor Freeze-up Protection (H99)

Malfunction Decision Conditions:

During anti-freezing control in cooling operation, when the indoor refrigerant liquid temperature < 0°C.

Malfunction Caused:

- 1 Faulty water pump.
- 2 Insufficient water flow rate in system.
- 3 Water leak in system.

No

- 4 2 way valve partially closed.
- 5 Clogged expansion valve or strainer.
- 6 Refrigerant shortage (refrigerant leakage).
- 7 Faulty indoor refrigerant liquid temperature sensor.
- 8 Faulty indoor unit PCB (main).

For safety reason and to prevent component breakdown, **Troubleshooting:** always switch off the power before remove and connect the component. Check the system water pump. Check for clogged expansion valve or strainer. Replace the faulty water Is the water pump working? - Replace the expansion pump. Yes Is the expansion valve or valve and/or strainer strainer clogged (ice formed)? - Reclaim and recharge Check the system water refrigerant **↓** No flow rate. Check refrigerant amount. Is the water pump speed Nο Readjust the water pump adjusted according to system speed. hydraulic external static pressure? Is the additional refrigerant Reclaim and recharge with amount filled correctly? correct amount of refrigerant. **↓** Yes Check the system water passage. Check the indoor refrigerant liquid temperature sensor Fix the system water Is there any water leakage? leakage. Does it conform to the sensor characteristic chart? No Yes Check the 2 way valve. Replace the indoor unit PCB (main). Nο Yes Is the 2 way valve partially Replace the indoor refrigerant Open the 2 way valve. closed? liquid temperature sensor.

16.5.16 Outdoor High Pressure Switch Activate (F12)

Malfunction Decision Conditions:

During operation of heating, when pressure 4.5MPa and above is detected by outdoor high pressure switch.

Malfunction Caused:

- 1 Dust accumulation on the outdoor unit heat exchanger.
- 2 Air short circuit at outdoor unit.
- 3 Faulty water pump.
- 4 Insufficient water flow rate in system.
- 5 Water leak in system.
- 6 2/3 way valve closed.
- 7 Clogged expansion valve or strainer.
- 8 Excessive refrigerant.
- 9 Faulty outdoor high pressure sensor and switch.
- 10 Faulty outdoor unit PCB.


Abnormality Judgment:

Continue 4 times in 20 minutes.

Troubleshooting:



For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



16.5.17 Compressor Rotation Failure (F14)

Malfunction Decision Conditions:


A compressor rotation failure is detected by checking the compressor running condition through the position detection circuit.

Malfunction Caused:

- 1 Compressor terminal disconnect.
- 2 Faulty outdoor unit PCB (main).
- 3 Faulty compressor.

Abnormality Judgment:

Continue 4 times in 20 minutes.



Replace the compressor.

Inverter checker

16.5.18 Outdoor Fan Motor (DC Motor) Mechanism Locked (F15)

Malfunction Decision Conditions:


The rotation speed detected by the Hall IC of the fan motor during fan motor operation is used to determine abnormal fan motor (feedback of rotation > 2550rpm or < 50rpm).

Malfunction Caused:

- 1 Operation stop due to short circuit inside the fan motor winding.
- 2 Operation stop due to breaking of wire inside the fan motor.
- 3 Operation stop due to breaking of fan motor lead wires.
- 4 Operation stop due to fan motor Hall IC malfunction.
- 5 Operation error due to faulty outdoor unit PCB.

Abnormality Judgment:

Continue 2 times in 30 minutes.



16.5.19 Input Over Current Detection (F16)

Malfunction Decision Conditions:

During operation of heating, when outdoor current above 27.9A is detected by the current transformer (CT) in the outdoor unit PCB.

Malfunction Caused:

- 1 Excessive refrigerant.
- 2 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue 3 times in 20 minutes.

For safety reason and to prevent component breakdown, **Troubleshooting:** always switch off the power before remove and connect the component. Get restarted and measure the AC current from the outdoor LIVE terminal. Nο Is the measured AC current Replace the outdoor unit over 27.9A? PCB (main). Yes Check refrigerant amount. Yes Reclaim and recharge with Excess refrigerant? correct amount of refrigerant. No Replace the outdoor unit

PCB (main).

16.5.20 Compressor Overheating (F20)

Malfunction Decision Conditions:

During operation of heating, when temperature above 112°C is detected by the compressor tank temperature sensor.

Malfunction Caused:

- 1 Faulty compressor tank temperature sensor.
- 2 2/3 way valve closed.
- 3 Refrigerant shortage (refrigerant leakage).
- 4 Clogged expansion valve or strainer.
- 5 Faulty outdoor unit PCB (main).
- 6 Faulty compressor.


Abnormality Judgment:

Continue 4 times in 30 minutes.

Troubleshooting:



For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



16.5.21 IPM Overheating (F22)

Malfunction Decision Conditions:

During operation of heating, when temperature 95°C is detected by the outdoor IPM temperature sensor.

Malfunction Caused:

- 1 Faulty outdoor unit fan motor.
- 2 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue 3 times in 30 minutes.

For safety reason and to prevent component breakdown, **Troubleshooting:** always switch off the power before remove and connect the component. Check the outdoor unit installation condition. Yes Is there any improper heat - Reinstall the outdoor unit radiation? - Remove the obstacle(s) No Νo Is the outdoor unit fan Replace the outdoor unit motor operating? fan motor. Yes - Defect in IPM - Replace the outdoor unit

PCB (main)

16.5.22 Output Over Current Detection (F23)

Malfunction Decision Conditions:


During operation of heating, when outdoor DC current is above 40.1 ± 5.0 A (for: UD07~09CE) OR 44.7 ± 5.0 A (for: UD12~16CE) is detected by the IPM DC Peak sensing circuitry in the outdoor unit PCB (main).

Malfunction Caused:

- 1 Faulty outdoor unit PCB (main).
- 2 Faulty compressor.

Abnormality Judgment:

Continue for 7 times.



16.5.23 Refrigeration Cycle Abnormality (F24)

Malfunction Decision Conditions:

- 1 During operation of heating, compressor frequency > Frated.
- 2 During operation of heating, running current: 0.65Å < I < 1.65Å.
- 3 During operation of heating, indoor refrigerant liquid temperature water inlet temperature < 5°C.

Malfunction Caused:

- 1 Faulty water inlet or indoor refrigerant liquid temperature sensors.
- 2 2/3 way valve closed.
- 3 Refrigerant shortage (refrigerant leakage).
- 4 Clogged expansion valve or strainer.
- 5 Faulty outdoor unit PCB (main).
- 6 Poor compression of compressor.


Abnormality Judgment:

Continue 2 times in 20 minutes.

Troubleshooting:



For safety reason and to prevent component breakdown, always switch off the power before remove and connect the component.



16.5.24 Four Way Valve Abnormality (F25)

Malfunction Decision Conditions:


During heating operation, when the indoor pipe temperature of thermostat ON indoor unit < 0°C.

Malfunction Caused:

- Faulty sensor.
- 2 Faulty connector connection.
- 3 Faulty outdoor unit PCB (noise filter/main).
- 4 Faulty four way valve.

Abnormality Judgment:

Continue 4 times in 30 minutes.



16.5.25 Outdoor High Pressure Switch Abnormal (F27)

Malfunction Decision Conditions:


During compressor stop, and outdoor high pressure switch is remain opened.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty switch.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue for 1 minute.



16.5.26 Outdoor Air Temperature Sensor Abnormality (F36)


Malfunction Decision Conditions:

During startup and operation of heating, the temperatures detected by the outdoor air temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:



16.5.27 Indoor Water Inlet Temperature Sensor Abnormality (F37)


Malfunction Decision Conditions:

During startup and operation of heating, the temperatures detected by the indoor water inlet temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB (main).

Abnormality Judgment:



16.5.28 Outdoor Discharge Pipe Temperature Sensor Abnormality (F40)


Malfunction Decision Conditions:

During startup and operation of heating, the temperatures detected by the outdoor discharge pipe temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:



16.5.29 Power Factor Correction (PFC) Abnormality (F41)

Malfunction Decision Conditions:


During operation of heating, when the PFC protection circuitry in the outdoor unit PCB (main) senses abnormal high DC voltage level.

Malfunction Caused:

- 1 Power supply surge.
- 2 Compressor windings not uniform.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:

Continue 4 times in 10 minutes.



16.5.30 Outdoor Pipe Temperature Sensor Abnormality (F42)


Malfunction Decision Conditions:

During startup and operation of heating, the temperatures detected by the outdoor pipe temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:



16.5.31 Outdoor Defrost Temperature Sensor Abnormality (F43)


Malfunction Decision Conditions:

During startup and operation of heating, the temperatures detected by the outdoor defrost temperature sensor are used to determine sensor error.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty outdoor unit PCB (main).

Abnormality Judgment:



16.5.32 Indoor Water Outlet Temperature Sensor Abnormality (F45)


Malfunction Decision Conditions:

During startup and operation of heating, the temperatures detected by the indoor water outlet temperature sensor are used to determine sensor errors.

Malfunction Caused:

- 1 Faulty connector connection.
- 2 Faulty sensor.
- 3 Faulty indoor unit PCB (main).

Abnormality Judgment:



16.5.33 Outdoor Current Transformer Open Circuit (F46)

Malfunction Decision Conditions:


A current transformer (CT) open circuit is detected by checking the compressor running frequency (≥ rated frequency) and CT detected input current (< 0.65A) for continuously 20 seconds.

Malfunction Caused:

- 1 CT defective.
- 2 Faulty outdoor unit PCB.
- 3 Compressor defective (low compression).

Abnormality Judgment:

Continue 3 times in 20 seconds.




16.5.34 Cooling High Pressure Overload Protection (F95)

Malfunction Decision Conditions:

During operation of cooling, when pressure 4.0MPa and above is detected by outdoor high pressure sensor.

Malfunction Caused:

- 1 Dust accumulation in the outdoor unit heat exchanger.
- 2 Air short circuit at outdoor unit.
- 3 2 way valve closed.
- 4 Faulty outdoor unit fan motor.
- 5 Clogged expansion valve or strainer.
- 6 Excessive refrigerant.
- 7 Faulty outdoor high pressure sensor.
- 8 Faulty outdoor unit PCB (main).



17. Disassembly and Assembly Instructions

Λ

WARNING


High Voltage are generated in the electrical parts area by the capacitor. Ensure that the capacitor has discharged sufficiently before proceeding with repair work. Failure to heed this caution may result in electric shocks.




WARNING

Be sure to switch off all the power supply before performing each of the below action.


17.1 To Remove The Cabinet Front Plate



17.2 To Remove The Cabinet Top Plate




17.3 To Remove The Cabinet Rear Plate




17.4 To Remove Pressure Gauge




17.5 To Remove RCCB




17.6 To Remove Transformer and Electronic Controller Board






17.7 To Remove Pressure Relief Valve and Air Purge Valve




⚠ When reinstall the water pipe, use grease or water at the joining.

17.8 To Remove Flow Switch




⚠ When reinstall the water pipe, use grease or water at the joining.

17.9 To Remove Water Pump



 \triangle When reinstall the water pipe, use grease or water at the joining.

17.10 To Remove Bottle Complete



⚠ When reinstall the water pipe, use grease or water at the joining.

18. Technical Data

18.1 Operation Characteristics


18.1.1 WH-MHF09D3E8


Heating Characteristics at Different Outdoor Air Temperature

Condition

Outdoor air temperature: 7°C (DBT), 6°C (WBT)

Indoor water inlet temperature : 30°C Indoor water outlet temperature : 35°C






18.1.2 WH-MHF12D9E8


Heating Characteristics at Different Outdoor Air Temperature

Condition

Outdoor air temperature : 7°C (DBT), 6°C (WBT)

Indoor water inlet temperature : 30°C Indoor water outlet temperature : 35°C





18.2 Heating Capacity Table

18.2.1 WH-MHF09D3E8

| Water Out | 3 | 30 | 3 | 35 | 4 | 10 | 4 | 1 5 |
|-------------|----------|-------------|----------|-------------|----------|-------------|----------|-------------|
| Outdoor Air | Capacity | Input Power |
| -15 | 9000 | 3500 | 9000 | 3750 | 8900 | 4050 | 8800 | 4300 |
| -7 | 9000 | 3100 | 9000 | 3330 | 9000 | 3600 | 8900 | 3870 |
| 2 | 9000 | 2470 | 9000 | 2650 | 9000 | 2950 | 9000 | 3250 |
| 7 | 9000 | 1860 | 9000 | 1980 | 9000 | 2250 | 9000 | 2500 |
| 16 | 9000 | 1500 | 9000 | 1600 | 9000 | 1850 | 9000 | 2100 |
| 25 | 12000 | 1700 | 12000 | 1800 | 12000 | 2050 | 10800 | 2180 |


| Water Out | 5 | 0 | 5 | 55 | 6 | 00 | 6 | 35 |
|-------------|----------|-------------|----------|-------------|----------|-------------|----------|-------------|
| Outdoor Air | Capacity | Input Power |
| -15 | 8600 | 4650 | 8500 | 4950 | 8000 | 5100 | 7800 | 5900 |
| -7 | 8900 | 4150 | 8900 | 4500 | 8900 | 5000 | 8900 | 5500 |
| 2 | 9000 | 3590 | 9000 | 3920 | 9000 | 4390 | 9000 | 4800 |
| 7 | 9000 | 2800 | 9000 | 3100 | 9000 | 3500 | 9000 | 4000 |
| 16 | 9000 | 2400 | 9000 | 2700 | 9000 | 3150 | 9000 | 3600 |
| 25 | 10600 | 2500 | 10200 | 2700 | 10000 | 2950 | 9800 | 3350 |

18.2.2 WH-MHF12D9E8


| Water Out | 3 | 30 | 35 | | 40 | | 45 | |
|-------------|----------|-------------|----------|-------------|----------|-------------|----------|-------------|
| Outdoor Air | Capacity | Input Power |
| -15 | 12000 | 5200 | 12000 | 5570 | 11000 | 5550 | 10600 | 5570 |
| -7 | 12000 | 4470 | 12000 | 4800 | 11500 | 4950 | 11200 | 5100 |
| 2 | 12000 | 3460 | 12000 | 3720 | 11500 | 3900 | 11300 | 4180 |
| 7 | 12000 | 2560 | 12000 | 2730 | 12000 | 3100 | 12000 | 3480 |
| 16 | 12000 | 2070 | 12000 | 2210 | 12000 | 2560 | 12000 | 2900 |
| 25 | 12000 | 1700 | 12000 | 1800 | 12000 | 2050 | 12000 | 2450 |

| Water Out | 5 | 0 | 5 | 55 | 6 | 60 | 6 | 35 |
|-------------|----------|-------------|----------|-------------|----------|-------------|----------|-------------|
| Outdoor Air | Capacity | Input Power |
| -15 | 10300 | 5670 | 9700 | 5800 | 9000 | 6050 | 8000 | 6150 |
| -7 | 10800 | 5200 | 10100 | 5320 | 9850 | 5700 | 9600 | 5950 |
| 2 | 11000 | 4550 | 10800 | 4900 | 10650 | 5350 | 10300 | 5630 |
| 7 | 12000 | 3850 | 12000 | 4320 | 12000 | 4900 | 12000 | 5450 |
| 16 | 12000 | 3450 | 12000 | 3900 | 12000 | 4350 | 12000 | 4800 |
| 25 | 12000 | 2680 | 12000 | 3000 | 12000 | 3450 | 12000 | 3900 |

18.3 Hydraulic Pump Performance





18.4 Usage Limitation




19. Exploded View and Replacement Parts List

19.1 (Refrigerant System)







- The above exploded view is for the purpose of parts disassembly and replacement. The non-numbered parts are not kept as standard service parts.


< Model: Refrigerant System >


| REF. NO. | DESCRIPTION & NAME | QTY. | WH-MHF09D3E8 | WH-MHF12D9E8 | REMARKS |
|----------|--------------------------------------|------|--------------|--------------|---------|
| 1 | BASE PAN ASS'Y | 1 | CWD52K1276 | ← | |
| 2 | COMPRESSOR | 1 | 4JD650XBA22 | ← | 0 |
| 3 | BUSHING - COMPRESSOR MOUNT | 3 | CWH50055 | ← | |
| 4 | NUT - COMPRESSOR MOUNT | 3 | CWH561049 | ← | |
| 4a | GASKET FOR TERMINAL COVER | 3 | CWB811017 | ← | |
| 5 | CRANKCASE HEATER | 1 | CWA341053 | ← | |
| 6 | CONDENSER COMPLETE | 1 | CWB32C3584 | ← | |
| 7 | HIGH PRESSURE SENSOR | 1 | CWA50C2570 | ← | |
| 8 | DISCHARGE MUFFLER | 1 | CWB121014 | ← | |
| 9 | PRESSURE SWITCH | 1 | CWA101013 | ← | |
| 10 | 3-WAYS VALVE (GAS) | 1 | CWB011700 | ← | 0 |
| 11 | 4-WAYS VALVE | 1 | CWB001046 | ← | 0 |
| 12 | 3-WAYS VALVE | 1 | CWB011699 | ← | |
| 13 | STRAINER | 4 | CWB111032 | ← | |
| 14 | LOW PRESSURE SENSOR | 1 | CWA50C2571 | · ← | |
| 20 | SOUND PROOF MATERIAL | 1 | CWG302265 | · ← | |
| 21 | SOUND PROOF MATERIAL | 1 | CWG302266 | <u>`</u> | |
| 22 | SOUND PROOF BOARD | 1 | CWH15K1031 | <u>←</u> | |
| 23 | V-COIL COMPLETE - 4-WAYS VALVE | 1 | CWA43C2169J | | 0 |
| 24 | V-COIL COMPLETE - EXP. VALVE | 1 | CWA43C21093 | ← | 0 |
| | | | | ← | |
| 25 | SENSOR-COMP. TEMP./COIL | 1 | CWA50C2730 | ← | 0 |
| 26 | SENSOR-COMP.DISCHARGE | 1 | CWA50C2576 | ← | 0 |
| 27 | SENSOR-COMPLETE | 1 | CWA50C2629 | ← | 0 |
| 27a | SENSOR-COMP. DEF. | 1 | CWA50C2577 | ← | 0 |
| 28 | CABINET REAR PLATE - COMPLETE | 1 | CWE02K1019A | ← | |
| 29 | CONTROL BOARD CASING | 1 | CWH10K1049 | ← | _ |
| 31 | TERMINAL BOARD ASS'Y | 1 | CWA28K1214 | ← | 0 |
| 38 | ELECTRONIC CONTROLLER (NOISE FILTER) | 1 | CWA745822 | ← | 0 |
| 44 | ELECTRONIC CONTROLLER (MAIN) | 1 | CWA73C6780R | CWA73C6781R | 0 |
| 46 | REACTOR | 3 | G0C293J00001 | ← | 0 |
| 48 | TERMINAL COVER | 1 | CWH171054 | ← | |
| 49 | NUT - TERMINAL COVER | 1 | CWH7080300J | ← | |
| 50 | FAN MOTOR BRACKET | 1 | CWD54K1024 | ← | |
| 50a | SCREW - FAN MOTOR BRACKET | 2 | CWH551040J | ← | |
| 53 | FAN MOTOR (UPPER) | 1 | EHDS83CAC | ← | 0 |
| 54 | FAN MOTOR (BOTTOM) | 1 | EHDS83DAC | ← | 0 |
| 54a | SCREW - FAN MOTOR MOUNT | 8 | CWH551323 | ← | |
| 55 | PROPELLER FAN ASSY | 2 | CWH00K1006 | ← | |
| 56 | NUT | 2 | CWH561092 | ← | |
| 57 | CABINET FRONT PLATE | 1 | CWE061098A | ← | |
| 58 | DISCHARGE GRILLE | 2 | CWE201073 | ← | |
| 59 | CABINET SIDE PLATE ASSY | 1 | CWE04K1023A | ← | |
| 60 | WIRE NET | 1 | CWD041103A | ← | |
| 61 | CABINET TOP PLATE CO. | 1 | CWE03C1105 | ← | |
| 62 | ACCESSORY - COMPLETE | 1 | CWH82C1839 | ← | |
| 66 | CABINET FRONT PLATE | 1 | CWE061274A | ← | |
| 67 | HANDLE | 2 | CWE161014 | ← | |
| 68 | TUBE ASSY (CAP.TUBE) | 1 | CWT07K1619 | ← | |
| 71 | EXPANSION VALVE | 2 | CWB051029 | ← | |
| 75 | ACCESORY CO. (DRAIN ELBOW) | 1 | CWG87C2030 | ← | |
| 76 | CRANKCASE HEATER (BASE PAN) | 1 | CWA341071 | ← | |
| 77 | V-COIL COMPLETE | 1 | CWA43C2335 | · ← | 0 |
| 78 | SENSOR - COMP. | 1 | CWA50C2807 | <u>`</u> | 0 |

| 80 | SOUND PROOF MATERIAL | 1 | CWG302635 | ← | |
|----|-------------------------|---|--------------|---|--|
| 81 | SOUND PROOF MATERIAL | 1 | CWG302599 | ← | |
| 82 | ELECTRO MAGNETIC SWITCH | 1 | K6C2AGA00002 | ← | |
| 83 | ELECTRO MAGNETIC SWITCH | 1 | K6C4E8A00001 | ← | |
| 84 | REACTOR | 3 | G0C153J00009 | ← | |
| 85 | PTC THERMISTORS | 1 | D4DDG1010001 | ← | |
| 86 | CAPACITOR-FM | 3 | DS441205NPQA | ← | |

- All parts are supplied from PAPAMY, Malaysia (Vendor Code: 00029488). "O" marked parts are recommended to be kept in stock.

19.2 (Water System)





- The above exploded view is for the purpose of parts disassembly and replacement. The non-numbered parts are not kept as standard service parts.

< Model: Water System >

| REF. NO. | DESCRIPTION & NAME | QTY. | WH-MHF09D3E8 | WH-MHF12D9E8 | REMARKS |
|----------|------------------------------|------|--------------|--------------|---------|
| 1 | BASE PAN ASS'Y | 1 | CWD52K1242 | ← | |
| 2 | HOT WATER COIL-COMPLETE | 1 | CWB90C1082 | ← | |
| 3 | RECEIVER | 1 | CWB141039 | ← | |
| 4 | FLOAT (FLOW SWITCH) | 1 | CWB601008 | ← | |
| 9 | PUMP | 1 | CWB532096 | ← | 0 |
| 16 | BOTTLE COMP. | 1 | CWH90C0026 | ← | |
| 17 | HEATER ASS'Y | 1 | CWA34K1029 | CWA34K1030 | |
| 18 | SOUND PROOF MATERIAL | 1 | CWG302592 | ← | |
| 18a | SOUND PROOF MATERIAL | 1 | CWG302594 | ← | |
| 19 | THERMOSTAT | 4 | CWA151065 | ← | 0 |
| 20 | ELECTRONIC CONTROLLER (MAIN) | 1 | CWA73C6731R | CWA73C6732R | 0 |
| 21 | TERMINAL BOARD ASS'Y | 1 | CWA28K1200 | ← | 0 |
| 25 | TERMINAL BOARD ASS'Y | 1 | CWA28K1211 | ← | 0 |
| 26 | TERMINAL BOARD ASS'Y | 1 | CWA28K1221 | ← | 0 |
| 27 | MAGNET RELAYS | 1 | K6C1AYY00004 | ← | 0 |
| 28 | TERMINAL BOARD ASS'Y | 1 | CWA28K1222 | ← | 0 |
| 29 | CIRCUIT BREAKER | 2 | CWA181008 | ← | 0 |
| 29a | CIRCUIT BREAKER | 1 | CWA181005 | ← | 0 |
| 30 | TRANSFORMER - COMPLETE | 1 | CWA40C1096 | ← | 0 |
| 31 | SENSOR - COMPLETE | 1 | CWA50C2749 | ← | 0 |
| 32 | REMOTE CONTROL COMPLETE | 1 | CWA75C4014 | ← | 0 |
| 33 | PRESSURE GAUGE | 1 | CWB070001 | ← | 0 |
| 34 | PRESSURE RELIEF VALVE | 1 | CWB621092 | ← | |
| 35 | PRESSURE RELIEF VALVE | 1 | CWB621094 | ← | |
| 39 | OPERATING INSTRUCTION | 1 | CWF568452 | ← | |
| 40 | INSTALLATION INSTRUCTION | 1 | CWF615252 | ← | |
| 42 | TUBE CONNECTOR - COMPLETE | 1 | CWT29C1050 | ← | |
| 43 | TUBE CONNECTOR - COMPLETE | 1 | CWT29C1062 | ← | |
| 44 | CONTROL BOARD COVER | 1 | CWH131420A | ← | |
| 45 | HANDLE | 2 | CWE161014 | ← | |
| 46 | CABINET SIDE PLATE ASS'Y | 1 | CWE04K1060A | ← | |
| 47 | CABINET FRONT PLATE | 1 | CWE061275A | ← | |
| 48 | HOLDER COUPLING | 1 | CWH351181A | ← | _ |

- All parts are supplied from PAPAMY, Malaysia (Vendor Code: 00029488).
- "O" marked parts are recommended to be kept in stock.